

SINGER

15K88,K91


ILLUSTRATED
LIST OF PARTS

FOR


Nos. 15K88 to 15K91
MACHINES




**A Trade Mark of THE SINGER MANUFACTURING CO.




121170




121547




15282






87589




96422


32672



125319



125261



125285




120855




120914



125336




125337



125253




125270




125021




125263







125262






125280












85893



36583



138



145



157



158



175



183




190




193



208



248



256



304



315



335



375



391



399



435



448



453



462



570



662




691



857

SS528



896




1085



1253



1285



1293



50053



50292



50353





50527




51002




51224




193586



193561



192542




192541



192543



198052




97382




97384

97383

51280



125359



125365



194113



125385



51582



246



51093



51319



192793



192691





192692




701719





125425



140175




80011




125417



125397




125419




125428



125421



125416



51682



45339

125316



45865



125400



125314



SS 528



NV95



96425



96426



96844





96427



96845









PLATE 4956—FULL SIZE




PLATE 4959—FULL SIZE




PLATE 4960—ONE-HALF SIZE






PLATE 4964—FULL SIZE

192989



192797



193629



50657



51293



LIST OF PARTS

FOR

15K88 to 15K91 Machines

CONTENTS

| | Page |
|--|------|
| Parts complete for 15K88 to 15K90 Machines | 47 |
| Parts special to 15K91 Machine | 53 |
| Attachments | 63 |
| Bobbin Winder | 61 |
| Embroidery Hoops | 65 |
| Hand Attachment | 66 |
| Numerical List of Parts | 75 |
| Obsolete Parts | 67 |

INSTRUCTIONS FOR ORDERING

In ordering from this List, the prelix and affix letters with the part number **MUST BE** quoted exactly as they are shown in the first column.

A number always indicates the same part in whatever List it may appear, or for whatever machine.

The affix letters (where shown) indicate the style of finish, as follows:—

- A. Hardened, Polished, Nickel Plated and Buffed.
- B. Polished, Nickel Plated and Buffed.
- C. Hardened only.
- D. Polished only.
- E. Soft, Not Polished.
- F. Hardened and Polished.
- G. Bright Rumbled and Nickel Plated.
- H. Blued.
- J. Nickel Plated only.
- K. Hardened and Nickel Plated.
- L. Brass Plated.
- M. Oxidized.
- R. Phosphate Coating Formed on Surface of Iron or Steel.
- S. Cadmium Plated.
- T. Copper Plated.
- U. Zinc Plated.
- V. Silver Plated.
- W. Polished and Nickel Plated.
- X. Black Oxide for Iron and Steel.
- Y. Black Nickel Plated only.
- Z. Chromium Plated.
- A.A. Buffed and Chromium Plated.
- A.B. Hardened, Polished, Buffed and Chromium Plated.
- A.E. Hardened, Bright Rumbled and Nickel Plated.
- A.F. Hardened, Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated.
- A.G. Alumilite (Plain).
- A.H. Alumilite (Dyed). Colour must be stated.
- A.J. Polished, Nickel Plated and Chromium Plated.
- A.K. Hardened, Polished, Nickel Plated and Chromium Plated.
- A.L. Heat Treated for Toughness.
- A.L.D. Heat Treated for Toughness and Polished.
- A.L.X. Heat Treated for Toughness and Black Oxide.
- A.S. Black Moulded Phenolic.
- A.T. Beige Moulded Phenolic.
- A.U. Brown Moulded Phenolic.
- A.W. Hardened then Flame Coated with Tungsten Carbide.
- B.A. Chrome Nickel, Satin Finish.
- B.B. Hardened and Chrome Nickel, Satin Finish.
- C.R. Hardened and Phosphate Coating Formed on Surface of Steel.
- C.U. Hardened and Zinc Plated.
- F.J. Hardened, Polished and Nickel Plated.
- T.A. Hardened, Polished, Copper and Nickel Plated and Buffed.
- T.B. Copper and Nickel Plated and Polished.
- T.J. Copper and Nickel Plated only.
- T.K. Hardened, Copper and Nickel Plated.
- T.L. Copper and Brass Plated.
- T.M. Copper Plated and Oxidized.
- X.C. Hardened and Black Oxide for Iron and Steel.
- Z.A. Hardened, Polished, Nickel Plated, Buffed and Chromium Plated.
- Z.B. Polished, Nickel Plated, Buffed and Chromium Plated.
- Z.C. Hardened and Chromium Plated.
- Z.D. Polished and Chromium Plated.
- Z.G. Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated.
- Z.I. Nickel and Chromium Plated.
- Z.T. Copper and Chromium Plated.

Parts marked with an asterisk () are furnished only when the repairs are made at Factory.*

PARTS COMPLETE

FOR

Nos. 15K88 to 15K90 MACHINES

G.B. Shuttle, Reverse Feed, Balanced Machine, for Family Use.

| No. | Plate | | | | | | | | |
|-------|-------|--|---|-----|-----|-----|-----|-----|-----|
| 25251 | - | Arm | ... | ... | ... | ... | ... | ... | ... |
| 25252 | - | " | 125251, with 435c, 448c, 15486 and 15498 | ... | ... | ... | ... | ... | ... |
| 2002 | 1954 | " | Dowel Pin (2) | ... | ... | ... | ... | ... | ... |
| 25331 | 1949 | " | Oil Pad (felt), for oiling Arm Shaft Back Bearing | ... | ... | ... | ... | ... | ... |
| 25333 | 1949 | " | " " Spring | ... | ... | ... | ... | ... | ... |
| 25334 | 1949 | " | " " " Cap | ... | ... | ... | ... | ... | ... |
| 138e | 1957 | " | Screw (3) | ... | ... | ... | ... | ... | ... |
| 15253 | 1947 | " | Shaft | ... | ... | ... | ... | ... | ... |
| 15254 | - | " | " 125253 with 15434, 15498 and 125045 | ... | ... | ... | ... | ... | ... |
| 5498 | 1954 | " | " Bushing | ... | ... | ... | ... | ... | ... |
| 435c | 1957 | " | " " Set Screw | ... | ... | ... | ... | ... | ... |
| 5425b | 2391 | " | Side Cover | ... | ... | ... | ... | ... | ... |
| 1224b | 1957 | " | " " Thumb Screw | ... | ... | ... | ... | ... | ... |
| 2007 | 1954 | " | Spool Pin | ... | ... | ... | ... | ... | ... |
| 5255 | - | Bed | ... | ... | ... | ... | ... | ... | ... |
| 256b | 1957 | Clamp Stop Motion Clamp Screw | ... | ... | ... | ... | ... | ... | ... |
| 248a | 1957 | " " " " Stop Screw | ... | ... | ... | ... | ... | ... | ... |
| 9020 | 1954 | " " " " Washer | ... | ... | ... | ... | ... | ... | ... |
| 342 | - | " " " Flanged Bushing | ... | ... | ... | ... | ... | ... | ... |
| 313 | 1954 | " " " " 15312 with two 462al | ... | ... | ... | ... | ... | ... | ... |
| 022 | 2552 | " " " " Pin | ... | ... | ... | ... | ... | ... | ... |
| 462al | 1957 | " " " " Set Screw | ... | ... | ... | ... | ... | ... | ... |
| 314 | - | Clamp Stop Motion, complete, Nos. 248a, 256b, 2020 and 15313 | ... | ... | ... | ... | ... | ... | ... |
| 021 | 1947 | Crank Connecting Rod with 125012, 125044 and two 896c | ... | ... | ... | ... | ... | ... | ... |
| 912 | - | " " " Cap | ... | ... | ... | ... | ... | ... | ... |
| 896c | 1957 | " " " Screw | ... | ... | ... | ... | ... | ... | ... |
| 175c | 1957 | " " " Hinge Screw | ... | ... | ... | ... | ... | ... | ... |
| 518j | 1958 | " " " " Nut | ... | ... | ... | ... | ... | ... | ... |
| 944 | 1949 | " " " Oil Pad (felt) | ... | ... | ... | ... | ... | ... | ... |
| 467 | 2551 | Face Plate | ... | ... | ... | ... | ... | ... | ... |
| 84 | - | " " 125367 with 15410, 125258 and 125369 | ... | ... | ... | ... | ... | ... | ... |
| 68 | - | " " 125384 with 857b, 50292b and 125317 | ... | ... | ... | ... | ... | ... | ... |
| 58 | 1951 | " " Tension Seat | ... | ... | ... | ... | ... | ... | ... |
| 28 | 2391 | " " Thread Guard | ... | ... | ... | ... | ... | ... | ... |
| 69 | 1950 | " " " 125428 with 125373 | ... | ... | ... | ... | ... | ... | ... |

| No. | Plate | | | | No. | Plate |
|--------|-------|---|--------------------|--|--------|-------|
| 125373 | --- | Face Plate | Thread Guard Rivet | ... | 125386 | 1960 |
| 125412 | 2551 | " | " | 125368 with 125418 | 125349 | 1950 |
| 190b | 1957 | " | " | Screw | 1813 | 1958 |
| | | | | | 125387 | 1960 |
| | | | | | 51289j | 1958 |
| 2835 | 792 | Feed Bar | ... | ... | | |
| 315c | 1957 | " | " | Screw Centre (2) | 15282 | 1152 |
| 1519j | 1958 | " | " | " " Nut (2) | 32672 | 1722 |
| 125045 | 2552 | Feed Cam and Counterbalance | with 1285c | ... | 51045c | 1958 |
| 1285c | 1957 | " | " | " " Position Screw | 25377 | 1951 |
| | | | | | 25272 | 1951 |
| 125261 | 1946 | Feed Dog, 12 teeth (14 teeth to the inch) | ... | ... | 25273 | |
| 208al | 1957 | " | " | Screw (2) | 25271 | 1919 |
| | | | | | 1498c | 1958 |
| 125262 | 1947 | Feed Forked Connection | with 175j | ... | 15248 | 1951 |
| 125340 | | " | " | " 125262 with 125335 | 25275 | |
| 175j | 1957 | " | " | Adjusting Screw | 51002c | 1957 |
| 51252c | 1958 | " | " | Hinge Screw (eccentric) | 570c | 1957 |
| 1520j | 1958 | " | " | " " Nut | 1520j | 1958 |
| 125047 | 2552 | " | " | Slide Block | 15276 | 1950 |
| 125335 | | " | " | " " 125017 with 1085c | 1341c | 1958 |
| 1085c | 1957 | " | " | " " Screw Stud | 5331 | |
| | | | | | 5285 | 1951 |
| 125263 | 1947 | Feed Lifting Rock Shaft | ... | ... | 5378 | 1951 |
| 125388 | 1960 | " | " | " " Crank with 157j | 1308j | 1958 |
| 157j | 1957 | " | " | " " Clamping Screw | 0515c | 1958 |
| 125389 | | " | " | " " complete, Nos. 51289j and 125386 to 125388 | 5549 | 1951 |
| | | | | | 125389 | 5280 |
| 125390 | | " | " | " " complete, Nos. 125263, 125349 and 125389 | 5048 | 1947 |
| 304c | 1957 | " | " | " " Screw Centre (2)... | 1246c | 1958 |
| 125344 | | " | " | " " 304c with 1513j (2) | 3049 | 2552 |
| 1513j | 1958 | " | " | " " Nut (2) | 1246c | 1958 |
| | | | | | 3056 | 1949 |
| 125397 | 2391 | Feed Regulator | ... | ... | 281 | 2551 |
| 125398 | | " | " | 125397 with 125381 | 363 | |
| 50353c | 1957 | " | " | Hinge Screw | 282 | |
| 125399 | 2552 | " | " | " " Friction Washer | 283 | 1950 |
| | | | | | 284 | |
| 45305 | 1960 | Feed Reversing Handle | ... | ... | 019 | 2552 |
| 125381 | | " | " | " 45305 with 1550j | 462al | 1957 |
| 1550j | 1960 | " | " | " Lock Nut | 170 | 2552 |
| | | | | | 330 | |
| 125270 | 1947 | Feed Rock Shaft | ... | ... | 360 | 2552 |
| 304c | 1957 | " | " | " Screw Centre (2) | | |
| 125344 | | " | " | " " 304c with 1513j (2) | | |
| 1513j | 1958 | " | " | " " Nut (2) | | |

| | | | | |
|---|-----------|---|-----------------|-----|
| Feed Throw-out Lever | with 1813 | ... | ... | ... |
| " | " | " | Retaining Ring | ... |
| " | " | " | Roller and Stud | ... |
| " | " | " | Spring | ... |
| " | " | " | Thumb Screw | ... |
| Hand Wheel, 2 1/2" pulley, for 15K88 and 15K89 Machines | ... | ... | ... | ... |
| " | " | 3 1/2" pulley, for 15K90 Machine | ... | ... |
| Machine Hinge Connection Set Screw (2) | ... | ... | ... | ... |
| Needle Bar with 52549 | ... | ... | ... | ... |
| " | " | Bushing | ... | ... |
| " | " | " 125272 with 125271 | ... | ... |
| " | " | Oil Pad (felt) | ... | ... |
| " | " | Set Screw | ... | ... |
| " | " | Connecting Link with 51002c | ... | ... |
| " | " | " 15218 with 125276 | ... | ... |
| " | " | " Adjusting Screw | ... | ... |
| " | " | " Hinge Screw | ... | ... |
| " | " | " " " Nut | ... | ... |
| " | " | " Stud with 1341c | ... | ... |
| " | " | " Set Screw | ... | ... |
| Needle Clamp with 140545c | ... | ... | ... | ... |
| " | " | 15331 with 51308j | ... | ... |
| " | " | Gib and Thread Guard | ... | ... |
| " | " | Position Screw | ... | ... |
| " | " | Thumb Screw | ... | ... |
| " | " | Stop Pin | ... | ... |
| Oscillating Rock Shaft with 125056 | ... | ... | ... | ... |
| " | " | " Centre (left) | ... | ... |
| " | " | " (") Set Screw | ... | ... |
| " | " | " (right) | ... | ... |
| " | " | " (") Set Screw | ... | ... |
| " | " | " Oil Wick (braided cotton) | ... | ... |
| Oscillating Shaft | ... | ... | ... | ... |
| " | " | 125281 with 2019 and 125295 | ... | ... |
| " | " | 125363 with 125283, 125298 and two 51229c | ... | ... |
| " | " | Crank | ... | ... |
| " | " | " 125282 with 462al and 125330 | ... | ... |
| " | " | " 125282 with 125330 and two 462al | ... | ... |
| " | " | " Pin | ... | ... |
| " | " | " Set Screw | ... | ... |
| " | " | " Slide Block | ... | ... |
| " | " | " " 15170 with 125060 | ... | ... |
| " | " | " Stud | ... | ... |

| No. | Plate | | | | | | |
|--------|-------|---|-----|-----|-----|-----|-----|
| 125061 | 2552 | Presser Bar | ... | ... | ... | ... | ... |
| 55621 | 1951 | " " Lifter | ... | ... | ... | ... | ... |
| 15486 | 2552 | " " " Hinge Stud | ... | ... | ... | ... | ... |
| 448c | 1957 | " " " " " Set Screw | ... | ... | ... | ... | ... |
| 80011 | 2391 | " " " Spring | ... | ... | ... | ... | ... |
| 2068 | 2552 | " " " Bracket with 453c | ... | ... | ... | ... | ... |
| 453c | 1957 | " " " " " Set Screw | ... | ... | ... | ... | ... |
| 2070 | 2552 | " " " Washer | ... | ... | ... | ... | ... |
| 45329 | | Presser Foot Hinge Pin | ... | ... | ... | ... | ... |
| 45319 | | " " Plate | ... | ... | ... | ... | ... |
| *32774 | | " " Shank | ... | ... | ... | ... | ... |
| 45321 | 1951 | Presser Foot (hinged), complete, Nos. 32774, 45319 and 45329 | ... | ... | ... | ... | ... |

NOTE.—No. 45321 is sent with machine unless otherwise specified on order.

| | | | | | | | |
|---------|------|---|-----|-----|-----|-----|-----|
| 125285 | 1946 | Presser Foot | ... | ... | ... | ... | ... |
| 51224b | 1957 | " " Thumb Screw | ... | ... | ... | ... | ... |
| *51228b | 2552 | Pressure Regulating Thumb Screw | ... | ... | ... | ... | ... |
| 66773 | ... | " " " " 51228b with 66752 | ... | ... | ... | ... | ... |
| 66752 | 2552 | " " " " Plug (felt) | ... | ... | ... | ... | ... |
| 2518 | 1954 | Shuttle Bobbin | ... | ... | ... | ... | ... |
| 125287 | 1949 | " " Case Latch | ... | ... | ... | ... | ... |
| 125320 | 1949 | " " " " Lever | ... | ... | ... | ... | ... |
| 2974 | 1954 | " " " " " Fulcrum Pin | ... | ... | ... | ... | ... |
| 2975 | 1954 | " " " " Spring | ... | ... | ... | ... | ... |
| 592e | 1957 | " " " " Stop Screw | ... | ... | ... | ... | ... |
| 125288 | | " " " Hinge, Nos. 2974, 125287 and 125320 | ... | ... | ... | ... | ... |
| 125290 | 1948 | " " " Position Plate | ... | ... | ... | ... | ... |
| 391j | 1957 | " " " " " Screw | ... | ... | ... | ... | ... |
| 125291 | 1949 | " " " with 591f, 592e, 2975, 125288 and 125293 | ... | ... | ... | ... | ... |
| 125292 | 1949 | " " Body | ... | ... | ... | ... | ... |
| 591f | 1957 | " " Tension Regulating Screw | ... | ... | ... | ... | ... |
| 125293 | 1949 | " " Spring | ... | ... | ... | ... | ... |
| 125294 | | Shuttle , $1\frac{1}{8}$ " diam., complete, Nos. 2518, 125291 and 125292 | ... | ... | ... | ... | ... |
| *125295 | 1949 | Shuttle Driver | ... | ... | ... | ... | ... |
| 125297 | | " " 125295 with two 1253c | ... | ... | ... | ... | ... |
| 125322 | 1949 | " " 125297 with 125298 and two 51229e | ... | ... | ... | ... | ... |
| 125298 | 1949 | " " Cushion Spring | ... | ... | ... | ... | ... |
| 51229e | 1958 | " " " " " Screw | ... | ... | ... | ... | ... |
| 2049 | 2552 | " " Pin | ... | ... | ... | ... | ... |
| 1253c | 1957 | " " Set Screw | ... | ... | ... | ... | ... |

| | | | | | | | |
|-------------------|------|--|-----|-----|-----|-----|-----|
| 125299 | 1948 | Shuttle Race Back | ... | ... | ... | ... | ... |
| 125301 | 1949 | " " " Position Pin | ... | ... | ... | ... | ... |
| 125302 | 1918 | " " " Spring | ... | ... | ... | ... | ... |
| 51261j | 1958 | " " " " " Thumb Screw | ... | ... | ... | ... | ... |
| 125303 | 1948 | " " " Body | ... | ... | ... | ... | ... |
| 125304 | | " " " 125303 with 125305 and two 662j | ... | ... | ... | ... | ... |
| 125300 | | " " " 125304 with 125290, two each 391j and 125301 | ... | ... | ... | ... | ... |
| 125305 | 1948 | " " Cap | ... | ... | ... | ... | ... |
| 662j | 1957 | " " " Screw | ... | ... | ... | ... | ... |
| 125306 | | Shuttle Race , complete, Nos. 51261j, 125299, 125300 and 125302 | ... | ... | ... | ... | ... |
| 115j | 1957 | " " Screw (2) | ... | ... | ... | ... | ... |
| 125336 | 1916 | Shuttle Race Slide | ... | ... | ... | ... | ... |
| 125337 | 1916 | " " " Spring | ... | ... | ... | ... | ... |
| 51282j | 1958 | " " " " " Screw | ... | ... | ... | ... | ... |
| 125338 | | Shuttle Race Slide , complete, Nos. 125336, 125337 and two 51282j | ... | ... | ... | ... | ... |
| 45306 | 1960 | Stitch Indicator Plate | ... | ... | ... | ... | ... |
| 335b | 1957 | " " " " " Screw (2) | ... | ... | ... | ... | ... |
| 45307 | | " " " " " Regulating Plate | ... | ... | ... | ... | ... |
| 45308 | 1960 | " " " " " 45307 with 45289 | ... | ... | ... | ... | ... |
| 45309 | | " " " " " 45308 with 45306, 45310, 51312b and 125400 | ... | ... | ... | ... | ... |
| 51312b | 1960 | " " " " " Thumb Screw | ... | ... | ... | ... | ... |
| *45289 | | " " " " " Bushing | ... | ... | ... | ... | ... |
| 125400 | 2391 | " " " " " Friction Washer | ... | ... | ... | ... | ... |
| 45310 | 1960 | " " " " " Washer (fibre) | ... | ... | ... | ... | ... |
| 2102 | 2552 | Tension Disc | ... | ... | ... | ... | ... |
| 125421 | 2391 | " " Indicator | ... | ... | ... | ... | ... |
| 125416 | 2391 | " " Flange | ... | ... | ... | ... | ... |
| 45865 | 2391 | " " " Stop Washer | ... | ... | ... | ... | ... |
| 51682b | 2391 | " " Regulating Thumb Nut with 45339 | ... | ... | ... | ... | ... |
| 45339 | 2391 | " " " " " Engaging Pin | ... | ... | ... | ... | ... |
| 125417 | 2391 | " " Releasing Pin | ... | ... | ... | ... | ... |
| 125314 | 2391 | " " Spring | ... | ... | ... | ... | ... |
| 140175c | 2391 | " " Stud | ... | ... | ... | ... | ... |
| 125420 | | " " " 140175c with 51682b | ... | ... | ... | ... | ... |
| 15110 | 2552 | " " Bushing | ... | ... | ... | ... | ... |
| 50292b | 1957 | " " Set Screw | ... | ... | ... | ... | ... |
| 125418 | | Tension , complete, Nos. 45865, 125314, 125316, 125416, 125417, 125419 to 125421 and two 2102 | ... | ... | ... | ... | ... |
| 26075 | 2552 | Thread Cutter and Holder | ... | ... | ... | ... | ... |

| No. | Plate | | | | | | |
|---------|-------|--|---|---|---------------------------|-----|-----|
| 15272 | 1954 | Thread Take-up Cam with 1293al | | | | | |
| *15434 | - - | " | " | " | 15272 with 570c and 1520j | ... | ... |
| 1293al | 1957 | " | " | " | Timing Screw | ... | ... |
| | | | | | | | |
| *125382 | 1951 | Thread Take-up Lever with 1822 | | | | | |
| 125383 | - - | " | " | " | 125382 with 50527c | ... | ... |
| 50527c | 1957 | " | " | " | Hinge Screw | ... | ... |
| 1822 | 1958 | " | " | " | Roller and Stud | ... | ... |
| | | | | | | | |
| 125316 | 2391 | Thread Take-up Spring | | | | | |
| 125317 | 1951 | " | " | " | Regulator | ... | ... |
| 857b | 1957 | " | " | " | " Set Screw | ... | ... |
| 125419 | 2391 | " | " | " | Thread Guard | ... | ... |
| | | | | | | | |
| 125319 | 1946 | Throat Plate for 125261 | | | | | |
| 691a | 1957 | " | " | " | Screw (2) | ... | ... |
| | | | | | | | |
| 125029 | --- | Drip Pan (for Cover Set) | | | | | |

PARTS SPECIAL

TO

No. 15K91 MACHINE

(OBSOLETE)

**C.B. Shuttle ; Reverse Feed ; Balanced Machine ; Solid Hand Wheel ;
P.G. Motor and SINGER Light ; for Family Use.**

This machine is the same as No. 15K88 with the following exceptions :

| No. | Plate | | | | | | |
|---------|-------|---|---|---|---|----------------------|-----|
| 51280b | 2091 | Clamp Stop Motion Clamp Screw | | | | | |
| 246a | 2091 | " | " | " | " Stop Screw | ... | ... |
| 125359 | 2091 | " | " | " | " Washer | ... | ... |
| 125360 | 1949 | " | " | " | Flanged Bushing | ... | ... |
| *125371 | | " | " | " | " | 125360 with 51280b | ... |
| 125372 | | " | " | " | " | 125360 with two 462a | ... |
| | | | | | | | |
| 125350 | 4960 | Hand Wheel with 125358 | | | | | |
| 125364 | - | " | " | " | 125350 with 125352 to 125355 and two 125385 | ... | ... |
| 125351 | | " | " | " | Gear (textolite) | ... | ... |
| 125352 | 4956 | " | " | " | 125351 with 125356 and 125357 | ... | ... |
| 125353 | 4956 | " | " | " | Collar with three 51281c | ... | ... |
| 51281c | 4956 | " | " | " | " Set Screw | ... | ... |
| 125354 | 4956 | " | " | " | Spring | ... | ... |
| 125385 | 2091 | " | " | " | " Cushion Pin (eccentric) | ... | ... |
| 125355 | 4956 | " | " | " | " Retaining Washer | ... | ... |
| 125356 | 4956 | " | " | " | " Stud | ... | ... |
| 125357 | 4956 | " | " | " | " Washer | ... | ... |
| 125358 | 4956 | " | " | " | Spring Stud | ... | ... |

MOTOR PARTS

| No. | Plate | | | | |
|---------|-------|--|-----|-----|-----|
| 193555 | 4960 | Armature, complete, for P.G.K. 3 Motor | ... | ... | ... |
| 193556 | — | " " " P.G.K. 5 Motor | ... | ... | ... |
| 193557 | — | " " " P.G.K. 6 Motor | ... | ... | ... |
| 193557 | — | " " " P.G.K. 7 Motor | ... | ... | ... |
| 193558 | — | " " " P.G.K. 8 Motor | ... | ... | ... |
| 193559 | — | " " " P.G.K. 9 Motor | ... | ... | ... |
| 193560 | — | " " " P.G.K. 10 Motor | ... | ... | ... |
| 193561 | 2090 | " " " P.G.K. 11 Motor | ... | ... | ... |
| 193561 | 2090 | " " " P.G.K. 12 Motor | ... | ... | ... |
| 193562 | — | " " " P.G.K. 15 Motor | ... | ... | ... |
| 193563 | — | " " " P.G.K. 87 Motor | ... | ... | ... |
| 193564 | — | " " " P.G.K. 90 Motor | ... | ... | ... |
| 193560 | — | " " " P.G.K. 92 Motor | ... | ... | ... |
| *193540 | — | Armature Core, complete | ... | ... | ... |
| *193528 | — | " Shaft | ... | ... | ... |
| 193523 | 4959 | " " Bearing Sleeve (commutator end) | ... | ... | ... |
| 447c | 4959 | " " " " (" ") Set Screw | ... | ... | ... |
| 193524 | 4959 | " " " " (front end) | ... | ... | ... |
| 50617b | 4959 | " " " " (" ") Cap Screw | ... | ... | ... |
| 447c | 4959 | " " " " (" ") Set Screw | ... | ... | ... |
| 193542 | 4959 | " " Oil Sling | ... | ... | ... |
| 193529 | 4959 | " " Pinion (spiral) with two 462al | ... | ... | ... |
| 462al | 1957 | " " " Set Screw | ... | ... | ... |
| 931275 | — | " Wire Separator (linen) | ... | ... | ... |
| 194591 | — | Brush (carbon) for 25 and 32 volts | ... | ... | ... |
| 192457 | 4959 | " (") " 50 to 145 volts (2) | ... | ... | ... |
| 193799 | — | " (") " 150 to 250 volts (2) | ... | ... | ... |
| 193543 | 4959 | " Cap (2) | ... | ... | ... |
| 192458 | 4959 | " Spring (2) | ... | ... | ... |
| 194113 | 2091 | " Tube (2) | ... | ... | ... |
| 193546 | 4959 | " " Insulating Bushing (2) | ... | ... | ... |
| 882e | 4959 | " " " " Set Screw | ... | ... | ... |
| 193536 | 4960 | Commutator, complete | ... | ... | ... |
| 193566 | — | Field Coil (left) for 193565 | ... | ... | ... |
| 193567 | — | " " (right) for 193565 | ... | ... | ... |
| 193565 | — | Field Coil, complete, Nos. 193566 and 193567, for P.G.K. 3 Motor | ... | ... | ... |
| 193569 | — | Field Coil (left) for 193568 | ... | ... | ... |
| 193570 | — | " " (right) for 193568 | ... | ... | ... |
| 193568 | — | Field Coil, complete, Nos. 193569 and 193570, for P.G.K. 5 Motor | ... | ... | ... |
| 193572 | — | Field Coil (left) for 193571 | ... | ... | ... |
| 193573 | — | " " (right) for 193571 | ... | ... | ... |
| 193571 | — | Field Coil, complete, Nos. 193572 and 193573, for P.G.K. 6 Motor | ... | ... | ... |
| 193575 | — | Field Coil (left) for 193574 | ... | ... | ... |
| 193576 | — | " " (right) for 193574 | ... | ... | ... |
| 193574 | — | Field Coil, complete, Nos. 193575 and 193576 for P.G.K. 7 Motor | ... | ... | ... |

MOTOR PARTS

| No. | Plate | | | | |
|---------|-------|---|-----|-----|-----|
| 193578 | — | Field Coil (left) for 193577 | ... | ... | ... |
| 193579 | — | " " (right) for 193577 | ... | ... | ... |
| 193577 | — | Field Coil, complete, Nos. 193578 and 193579 for P.G.K. 8 Motor | ... | ... | ... |
| 193581 | — | Field Coil (left) for 193580 | ... | ... | ... |
| 193582 | — | " " (right) for 193580 | ... | ... | ... |
| 193580 | — | Field Coil, complete, Nos. 193581 and 193582 for P.G.K. 9 Motor | ... | ... | ... |
| 193584 | — | Field Coil (left) for 193583 | ... | ... | ... |
| 193585 | — | " " (right) for 193583 | ... | ... | ... |
| 193583 | — | Field Coil, complete, Nos. 193584 and 193585 for P.G.K. 10 and P.G.K. 11 Motors | ... | ... | ... |
| 193587 | — | Field Coil (left) for 193586 | ... | ... | ... |
| 193588 | — | " " (right) for 193586 | ... | ... | ... |
| 193586 | 2090 | Field Coil, complete, Nos. 193587 and 193588 for P.G.K. 12 Motor | ... | ... | ... |
| 193590 | — | Field Coil (left) for 193589 | ... | ... | ... |
| 193591 | — | " " (right) for 193589 | ... | ... | ... |
| 193589 | — | Field Coil, complete, Nos. 193590 and 193591 for P.G.K. 15 Motor | ... | ... | ... |
| 193593 | — | Field Coil (left) for 193592 | ... | ... | ... |
| 193594 | — | " " (right) for 193592 | ... | ... | ... |
| 193592 | — | Field Coil, complete, Nos. 193593 and 193594 for P.G.K. 87 Motor | ... | ... | ... |
| 193596 | — | Field Coil (left) for 193595 | ... | ... | ... |
| 193597 | — | " " (right) for 193595 | ... | ... | ... |
| 193595 | — | Field Coil, complete, Nos. 193596 and 193597 for P.G.K. 90 Motor | ... | ... | ... |
| 193599 | — | Field Coil (left) for 193598 | ... | ... | ... |
| 193600 | — | " " (right) for 193598 | ... | ... | ... |
| 193598 | — | Field Coil, complete, Nos. 193599 and 193600 for P.G.K. 92 Motor | ... | ... | ... |
| 727511 | 4959 | Field Coil Lead Bushing (rubber) | ... | ... | ... |
| 195834 | — | " " " Terminal Clip (2) | ... | ... | ... |
| 192424 | 4959 | Field Coil Retainer (2) | ... | ... | ... |
| 193541 | 4960 | " Core, complete | ... | ... | ... |
| 51286r | 4959 | " " Screw (2) | ... | ... | ... |
| 193526 | 4959 | Grease Wick | ... | ... | ... |
| 193525 | — | " " 193526 with 193527 (2) | ... | ... | ... |
| 193527 | 4959 | " " Spring | ... | ... | ... |
| 51284r | 4959 | " " " Cap Screw (2) | ... | ... | ... |
| 193640 | 4959 | " " " Retainer (2) | ... | ... | ... |
| *192852 | — | Lead Cord | ... | ... | ... |
| 192851 | — | Lead Cord, complete, from lamp socket to three-pin terminal, for Knee and Treadle Control, Nos. 192790, 192852, 192989 and Plug | ... | ... | ... |

MOTOR PARTS

| No. | Plate | | | | |
|---------|-------|---|-----|-----|-----|
| *192820 | - | Lead Cord, 8ft. long, for 192875 | ... | ... | ... |
| 192874 | - | " " 3 ft. 10 ins. long, for 192875 | ... | ... | ... |
| 192875 | - | Lead Cord, complete, from lamp socket to three-pin terminal and controller, for Foot Controller, Nos. 192348, 192820, 192874, 192989, Plug and two 195834 | ... | ... | ... |
| 192348 | 1949 | Lead Bushing | ... | ... | ... |
| 195834 | --- | Lead Terminal Clip | ... | ... | ... |
| 193544 | 4960 | Motor Cover | ... | ... | ... |
| 224b | 4959 | " " Screw (2) | ... | ... | ... |
| 193522 | --- | " " Frame | ... | ... | ... |
| 193545 | 4960 | " " 193522 with 193523, 193524, two each 447c and 882e | ... | ... | ... |
| *193644 | --- | Motor Frame 193545 with 190b, 51303b, 51319b, 125326, 125365, 125366, 125376 and 125462 | ... | ... | ... |
| 51285e | 4959 | Motor Frame Screw (2) | ... | ... | ... |
| 899418 | --- | Name Plate for P.G.K. 7 Motor | ... | ... | ... |
| 899419 | - | " " " all P.G.K. Motors except P.G.K. 7 | ... | ... | ... |
| 192790 | 4959 | Three-Pin Terminal Adaptor Bushing | ... | ... | ... |
| *192643 | --- | " " (female half) Housing (upper) | ... | ... | ... |
| *192644 | --- | " " (" ") " (lower) | ... | ... | ... |
| 51093r | 2091 | " " (" ") " Screw | ... | ... | ... |
| 1768r | 4959 | " " (" ") " Nut | ... | ... | ... |
| 192692 | 2091 | " " (" ") Insert Clamp | ... | ... | ... |
| 192691 | 2091 | " " (" ") " Sleeve | ... | ... | ... |
| 192089 | 4964 | Three-Pin Terminal (female half), complete, Nos. 192643, 192644, two each 1768r, 51093r, three each 192691 and 192692 | ... | ... | ... |
| *192642 | --- | Three-Pin Terminal Body (male half) | ... | ... | ... |
| *193700 | --- | " " " (" ") 192642 with three 192793 | ... | ... | ... |
| 192793 | 2091 | " " " (male half) Post | ... | ... | ... |
| 51582 | 2091 | " " " (" ") " Thumb Nut | ... | ... | ... |
| 701719 | 2091 | " " " (" ") " Washer | ... | ... | ... |
| 192797 | 4964 | Three-Pin Terminal Body (male half), complete, Nos. 193700, three each 51582 and 701719 | ... | ... | ... |
| 193629 | 4964 | Three-Pin Terminal Body (male half) Bracket | ... | ... | ... |
| 51293e | 4964 | " " " (" ") " Screw | ... | ... | ... |
| 50657r | 4964 | " " " (" ") Screw | ... | ... | ... |
| 190439 | --- | Tube, filled with Singer Lubricant, for Electric Motors | ... | ... | ... |
| 190613 | --- | " 190439 with 190612 | ... | ... | ... |
| 190612 | --- | " Carton (paper) | ... | ... | ... |

PLUGS

| No. | Plate | | | | |
|--------|-------|--|-----|-----|-----|
| 198052 | 2090 | Two-Pin Plug | ... | ... | ... |
| 198108 | --- | " " (Norwegian) | ... | ... | ... |
| 198138 | --- | " " (Danish) | ... | ... | ... |
| 198367 | --- | " " (Swiss) | ... | ... | ... |
| 97382 | 2090 | Bayonet Plug, complete, Nos. 97383 and 97384 | ... | ... | ... |
| 97383 | 2090 | " " Body for 97382 | ... | ... | ... |
| 97384 | 2090 | " " Cover for 97382 | ... | ... | ... |
| 192540 | --- | Screw Plug, complete, Nos. 192541 and 192542 | ... | ... | ... |
| 192541 | 2090 | " " Base for 192540 | ... | ... | ... |
| 192542 | 2090 | " " Cap with 192543 for 192540 | ... | ... | ... |
| 192543 | 2090 | " " Flash Disc (fibre) for 192542 | ... | ... | ... |

SINGER LIGHT

(for details see Form K5550, List of Parts for B.R.K. Motors)

| No. | Plate | |
|--|-------|---|
| 193294 | × | SINGER Light (moulded, less lamp), complete, Nos. 691j, 97359, 191785, 193248, 193289, 193400, 193421, 193431, 193437, 701842 and two 191786 |
| 194120 | | SINGER Light Lamp |
| <i>NOTE.—When ordering lamps for SINGER Lights, it is necessary to state the exact voltage required.</i> | | |

Example :— 194120, 240 volts

Bobbin Winder

for Hand Wheel No. 15282 or No. 32672

| No. | Plate | | | | | | | | |
|---------|-------|--|-----|-----|-----|-----|-----|-----|-----|
| 15072 | 1954 | Bobbin Position Pin | ... | ... | ... | ... | ... | ... | ... |
| †125324 | 1955 | Bracket (belt cover) | ... | ... | ... | ... | ... | ... | ... |
| 158e | 1957 | " Screw (2) | ... | ... | ... | ... | ... | ... | ... |
| 66670 | 1955 | Frame | ... | ... | ... | ... | ... | ... | ... |
| 125366 | | " 66670 with 15288 and 125068 | ... | ... | ... | ... | ... | ... | ... |
| 51319b | 1955 | " Hinge Screw | ... | ... | ... | ... | ... | ... | ... |
| 66601 | 1955 | " Spring | ... | ... | ... | ... | ... | ... | ... |
| 15287 | 1955 | Friction Ring (rubber) | ... | ... | ... | ... | ... | ... | ... |
| 15288 | 1955 | Pulley | ... | ... | ... | ... | ... | ... | ... |
| 125068 | 1955 | Spindle with 15072 | ... | ... | ... | ... | ... | ... | ... |
| 2007 | 1951 | Spool Pin | ... | ... | ... | ... | ... | ... | ... |
| 125376 | 1955 | Stop Latch | ... | ... | ... | ... | ... | ... | ... |
| 51303b | 1955 | " " Hinge Screw | ... | ... | ... | ... | ... | ... | ... |
| 125462 | 1955 | " " Spring | ... | ... | ... | ... | ... | ... | ... |
| 125395 | 1955 | Tension Bracket | ... | ... | ... | ... | ... | ... | ... |
| 125396 | ... | " " complete, Nos. 45847, 45915, 45916, 125395 and 140138b | ... | ... | ... | ... | ... | ... | ... |
| 193b | 1957 | " " Screw | ... | ... | ... | ... | ... | ... | ... |
| 7071 | 1955 | " " Washer | ... | ... | ... | ... | ... | ... | ... |
| 45915 | 1955 | " Disc | ... | ... | ... | ... | ... | ... | ... |
| 45916 | 1955 | " " Screw Washer | ... | ... | ... | ... | ... | ... | ... |
| 45847 | 1955 | " " Spring | ... | ... | ... | ... | ... | ... | ... |
| 140138b | 1955 | " Screw | ... | ... | ... | ... | ... | ... | ... |
| 125326 | 1955 | Tripping Arm | ... | ... | ... | ... | ... | ... | ... |
| 190b | 1957 | " " Screw | ... | ... | ... | ... | ... | ... | ... |
| †125327 | 1955 | Bobbin Winder (automatic), complete, Nos. 190b, 15287, 51303b, 51319b, 66601, 125324, 125326, 125366, 125376 and 125462 | ... | ... | ... | ... | ... | ... | ... |

† In ordering it is necessary to state Class of Machine.

Bobbin Winder Parts

for No. 15K91 Machine
(OBSOLETE)

| No. | Plate | | | | | | | |
|---------|-------|--|-----|-----|-----|-----|-----|-----|
| 15072 | 1954 | Bobbin Position Pin | ... | ... | ... | ... | ... | ... |
| 66670 | 1955 | Frame | ... | ... | ... | ... | ... | ... |
| 125366 | --- | " 66670 with 15288 and 125068 | ... | ... | ... | ... | ... | ... |
| 51319b | 1955 | " Hinge Screw | ... | ... | ... | ... | ... | ... |
| 125365 | 2091 | " Spring | ... | ... | ... | ... | ... | ... |
| 15287 | 1955 | Friction Ring (rubber) | ... | ... | ... | ... | ... | ... |
| 15288 | 1955 | Pulley | ... | ... | ... | ... | ... | ... |
| 125068 | 1955 | Spindle with 15072 | ... | ... | ... | ... | ... | ... |
| 2007 | 1954 | Spool Pin | ... | ... | ... | ... | ... | ... |
| 125376 | 1955 | Stop Latch | ... | ... | ... | ... | ... | ... |
| 51303b | 1955 | " " Hinge Screw | ... | ... | ... | ... | ... | ... |
| 125462 | 1955 | " " Spring | ... | ... | ... | ... | ... | ... |
| 125395 | 1955 | Tension Bracket | ... | ... | ... | ... | ... | ... |
| 125396 | --- | " " complete, Nos. 45847, 45915, 45916, 125395 and 140138b | ... | ... | ... | ... | ... | ... |
| 193b | 1957 | " " Screw | ... | ... | ... | ... | ... | ... |
| 7071 | 1955 | " " " Washer | ... | ... | ... | ... | ... | ... |
| 45915 | 1955 | " Disc | ... | ... | ... | ... | ... | ... |
| 45916 | 1955 | " " Screw Washer | ... | ... | ... | ... | ... | ... |
| 45847 | 1955 | " " Spring | ... | ... | ... | ... | ... | ... |
| 140138b | 1955 | " Screw | ... | ... | ... | ... | ... | ... |
| 125326 | 1955 | Tripping Arm | ... | ... | ... | ... | ... | ... |
| 190b | 1957 | " " Screw | ... | ... | ... | ... | ... | ... |

Attachments

Attachment Set
Supplied with Machine

| No. | Plate | | | | | | | |
|--------|-------|---|-----|-----|-----|-----|-----|-----|
| 121464 | 2574 | Binder | ... | ... | ... | ... | ... | ... |
| 36865 | 2574 | Edge Stitcher | ... | ... | ... | ... | ... | ... |
| 121441 | 2574 | Gathering Foot (double toe) | ... | ... | ... | ... | ... | ... |
| 35931 | 2574 | Hemmer (adjustable) | ... | ... | ... | ... | ... | ... |
| 15 x 1 | --- | Needles (6) | ... | ... | ... | ... | ... | ... |
| 86642 | 2574 | Ruffler | ... | ... | ... | ... | ... | ... |
| 25537 | 2574 | Screw Driver (machine) | ... | ... | ... | ... | ... | ... |
| 120378 | 2574 | " " (bobbin case) | ... | ... | ... | ... | ... | ... |
| 8879 | 2574 | Spool Pin Washer (cloth) | ... | ... | ... | ... | ... | ... |
| 160810 | --- | Set of Attachments, complete, Nos. 25537, 35931, 36865, 86642, 120378, 121441, 121464, two 8879 and six needles | ... | ... | ... | ... | ... | ... |
| 160811 | --- | Set of Attachments (less needles), complete, Nos. 25537, 35931, 36865, 86642, 120378, 121441, 121464 and two 8879 | ... | ... | ... | ... | ... | ... |
| 120855 | 1946 | Hemmer (foot) $\frac{5}{64}$ " hem | ... | ... | ... | ... | ... | ... |
| 2518 | 1954 | Shuttle Bobbin (4) | ... | ... | ... | ... | ... | ... |
| 120861 | --- | Tin of Oil (3 oz.) | ... | ... | ... | ... | ... | ... |

The following Attachments may be purchased at an additional charge:

| | | | | | | | | |
|--------|------|---|-----|-----|-----|-----|-----|-----|
| 25525 | 2719 | Bias Gauge | ... | ... | ... | ... | ... | ... |
| 25527b | 2719 | Cloth Guide | ... | ... | ... | ... | ... | ... |
| 50053b | 2719 | " " and Underbraider Thumb Screw | ... | ... | ... | ... | ... | ... |
| 120914 | 1946 | Feller (foot) | ... | ... | ... | ... | ... | ... |
| 120687 | --- | Imitation Hemstitching Attachment with Yielding Presser Plate | ... | ... | ... | ... | ... | ... |
| 35932 | 2719 | Quilter | ... | ... | ... | ... | ... | ... |
| 121170 | 909 | Ruffler Shirring Plate | ... | ... | ... | ... | ... | ... |
| 25539 | 2719 | Stiletto | ... | ... | ... | ... | ... | ... |
| 36583 | 1956 | Tucker | ... | ... | ... | ... | ... | ... |
| 121517 | 909 | Underbraider | ... | ... | ... | ... | ... | ... |

Art Work and Darning

| No. | Plate | | | | |
|--------|-------|--------------------------------|-----|-----|-----|
| 85893 | 1956 | Embroidery Foot (for art work) | ... | ... | ... |
| 121094 | 2719 | Darning Foot (spring) | ... | ... | ... |

Cording Feet

For Stitching on Edge and Inserting Cord

| No. | Plate | | | | |
|--------|-------|-------------------------|-----|-----|-----|
| 160845 | 2719 | Presser Foot (left toe) | ... | ... | ... |
| 160846 | 2719 | " " (right toe) | ... | ... | ... |

Imitation Hemstitching Attachment

| No. | Plate | | | | |
|--------|-------|-----------------------------|-----|-----|-----|
| 120687 | 1956 | with Yielding Presser Plate | ... | ... | ... |

Presser Feet

| No. | Plate | | | | |
|---------|-------|--|-----------------------------|-----|-----|
| 121875 | — | Presser Foot, for 121877 | <i>obsolete</i> | ... | ... |
| 140347w | — | " " Adjusting Thumb Screw, for 121877 | <i>obsolete</i> | ... | ... |
| 121876 | — | " " Body, for 121877 | <i>obsolete</i> | ... | ... |
| 121877 | 2719 | Presser Foot (adjustable for sewing on the right or left side of the needle), complete, Nos. 121875, 121876 and 140347w, for Cording and Slide Fastener Work | <i>obsolete, use 161127</i> | ... | ... |
| 121441 | 2574 | Presser Foot (double toe) for gathering | ... | ... | ... |

Presser Foot

(for Cording and Slide Fastener Work)

| No. | Plate | | | | |
|--------|-------|--|-----|-----|-----|
| 140728 | — | Presser Foot Adjusting Thumb Screw | ... | ... | ... |
| 161122 | — | " " " " Spring | ... | ... | ... |
| 161123 | — | " " Hinge Pin | ... | ... | ... |
| 161124 | — | " " Plate | ... | ... | ... |
| 161125 | — | " " Shank (adjustable) | ... | ... | ... |
| 161126 | — | " " (stationary) | ... | ... | ... |
| 161127 | — | Presser Foot (hinged, adjustable) for sewing on the right or left side of the needle, complete, Nos. 140728 and 161122 to 161126 | ... | ... | ... |

| | | | | | |
|-------|------|---|-----|-----|-----|
| 96417 | — | Round, 5 $\frac{3}{8}$ " diam. \times 7 $\frac{m}{m}$ high, complete, Nos. 101348 and 101349 | ... | ... | ... |
| 96418 | 2193 | " 7" " \times 7 $\frac{m}{m}$ " " Nos. 101350 and 101351 | ... | ... | ... |
| 96419 | — | " 8" " \times 7 $\frac{m}{m}$ " " Nos. 101352 and 101353 | ... | ... | ... |
| 96420 | — | " 10" " \times 7 $\frac{m}{m}$ " " Nos. 101354 and 101355 | ... | ... | ... |
| 96421 | — | " 12" " \times 7 $\frac{m}{m}$ " " Nos. 101356 and 101357 | ... | ... | ... |
| 96423 | — | Oval, 9" \times 4 $\frac{1}{2}$ " \times 7 $\frac{m}{m}$ high, complete, Nos. 101360 and 101361 | ... | ... | ... |
| 96424 | — | " 12" \times 5 $\frac{1}{2}$ " \times 7 $\frac{m}{m}$ " " Nos. 101362 and 101363 | ... | ... | ... |

Embroidery Hoops (Plain)

(BIRCH)

| No. | Plate | | | | |
|-------|-------|---|-----------------|-----|-----|
| 87586 | — | Round, 5 $\frac{3}{8}$ " diam. \times 7 $\frac{m}{m}$ high | 101336 & 101337 | ... | ... |
| 96416 | — | " 7" " \times 7 $\frac{m}{m}$ " " | 101346 & 101347 | ... | ... |
| 87589 | 1221 | " 8" " \times 7 $\frac{m}{m}$ " " | 101338 & 101339 | ... | ... |
| 87593 | — | " 10" " \times 7 $\frac{m}{m}$ " " | 101340 & 101341 | ... | ... |
| 87595 | — | " 12" " \times 7 $\frac{m}{m}$ " " | 101342 & 101343 | ... | ... |
| 96422 | 1221 | Oval, 9" \times 4 $\frac{1}{2}$ " \times 7 $\frac{m}{m}$ high | 101358 & 101359 | ... | ... |
| 87597 | — | " 12" \times 5 $\frac{1}{2}$ " \times 7 $\frac{m}{m}$ " " | 101344 & 101345 | ... | ... |

Embroidery Hoops (with Clamp)

(BIRCH)

| No. | Plate | | | | |
|--------|-------|---|--------------------------------|----------------|-----|
| 96417 | — | Round, 5 $\frac{3}{8}$ " diam. \times 7 $\frac{m}{m}$ high, with SS528j, NN95j, two | 96425 | and four 96127 | |
| 96418 | — | " 7" " \times 7 $\frac{m}{m}$ " " SS528j, NN95j, two | 96426 | and four 96427 | |
| 96419 | — | " 8" " \times 7 $\frac{m}{m}$ " " SS528j, NN95j, two | 96426 | and four 96427 | |
| 96420 | — | " 10" " \times 7 $\frac{m}{m}$ " " SS528j, NN95j, two | 96426 | and four 96427 | |
| 96421 | — | " 12" " \times 7 $\frac{m}{m}$ " " SS528j, NN95j, two | 96844 | and four 96845 | |
| 96423 | — | Oval, 9" \times 4 $\frac{1}{2}$ " \times 7 $\frac{m}{m}$ high, with SS528j, NN95j, 96425, 96426 and | four 96127 | | |
| 96424 | — | " 12" \times 5 $\frac{1}{2}$ " \times 7 $\frac{m}{m}$ " " SS528j, NN95j, 96425, 96426 and | four 96427 | | |
| 96425 | 2399 | Clamping Bracket for 96417, 96418 and 96421 | 101349, 101361 & 101363 | | |
| 96426 | 2399 | " " " 96418 to 96420, 96423 and 96424 | 101351, 101353 | | |
| 96844 | 2399 | " " " 96421 101357 | 101355, 101361, 101363 | | |
| 96427 | 2399 | " " " Rivet for 96417 to 96420, 96423 and 96424 | 101349, 101351, 101353, 101355 | | |
| 96845 | 2399 | " " " 96421 101357 | 101361 & 101362 | | |
| SS528j | 2399 | " " " Screw | ... | ... | ... |
| NN95j | 2399 | " " " Nut | ... | ... | ... |

| | | | | | | |
|--------|-----|-----------------|-------------------|-----|-----|-----|
| 101336 | --- | Embroidery Hoop | (outer) for 87586 | ... | ... | ... |
| 101337 | --- | " | (inner) for 87586 | ... | ... | ... |
| 101338 | --- | " | (outer) for 87589 | ... | ... | ... |
| 101339 | --- | " | (inner) for 87589 | ... | ... | ... |
| 101340 | --- | " | (outer) for 87593 | ... | ... | ... |
| 101341 | --- | " | (inner) for 87593 | ... | ... | ... |
| 101342 | --- | " | (outer) for 87595 | ... | ... | ... |
| 101343 | --- | " | (inner) for 87595 | ... | ... | ... |
| 101344 | --- | " | (outer) for 87597 | ... | ... | ... |
| 101345 | --- | " | (inner) for 87597 | ... | ... | ... |
| 101346 | --- | " | (outer) for 96416 | ... | ... | ... |
| 101347 | --- | " | (inner) for 96416 | ... | ... | ... |
| 101358 | --- | " | (outer) for 96422 | ... | ... | ... |
| 101359 | --- | " | (inner) for 96422 | ... | ... | ... |

| | | | | | | |
|--------|-----|-----------------|--|-----|-----|-----|
| 101348 | --- | Embroidery Hoop | (inner) for 96417 | ... | ... | ... |
| 101349 | --- | " | (outer) with SS528j, NN95j, two 96425 and four 96427, for 96417 | ... | ... | ... |
| 101350 | --- | " | (inner) for 96418 | ... | ... | ... |
| 101351 | --- | " | (outer) with SS528j, NN95j, two 96426 and four 96427, for 96418 | ... | ... | ... |
| 101352 | --- | " | (inner) for 96419 | ... | ... | ... |
| 101353 | --- | " | (outer) with SS528j, NN95j, two 96426 and four 96427, for 96419 | ... | ... | ... |
| 101354 | --- | " | (inner) for 96420 | ... | ... | ... |
| 101355 | --- | " | (outer) with SS528j, NN95j, two 96426 and four 96427, for 96420 | ... | ... | ... |
| 101356 | --- | " | (inner) for 96421 | ... | ... | ... |
| 101357 | --- | " | (outer) with SS528j, NN95j, two 96426 and four 96427, for 96421 | ... | ... | ... |
| 101360 | --- | " | (inner) for 96423 | ... | ... | ... |
| 101361 | --- | " | (outer) with SS528j, NN95j, 96425, 96426 and four 96427, for 96423 | ... | ... | ... |
| 101362 | --- | " | (inner) for 96424 | ... | ... | ... |
| 101363 | --- | " | (outer) with SS528j, NN95j, 96425, 96426 and four 96427, for 96424 | ... | ... | ... |

Embroidery Hoop (with Spring)

(BIRCH)

| No. | Plate | |
|--------|-------|---|
| 101364 | --- | Hoop (inner) for 101246 ... |
| 101365 | --- | " (outer) with Spring, for 101246 ... |
| 101246 | --- | " (round) 10" diam \times $\frac{7}{16}$ " high, complete, Nos. 101364 and 101365 ... |

Hand Attachment

| No. | Plate | | | | | | | | |
|--------|-------|---|----------------------------|------------------------------------|----------------|-------------------------|-----|-----|-----|
| 94050 | 2284 | Body | ... | ... | ... | ... | ... | ... | ... |
| 94027 | 2284 | " | Bracket | ... | ... | ... | ... | ... | ... |
| 183e | 2114 | " | " | Screw | ... | ... | ... | ... | ... |
| 94028 | 2114 | Crank Handle | (wood) | ... | ... | ... | ... | ... | ... |
| 94029b | 2114 | " | " | Spindle | ... | ... | ... | ... | ... |
| 94030b | 2114 | " | " | " | Flange (loose) | ... | ... | ... | ... |
| 94069 | 2114 | " | " | Hinge Pin | ... | ... | ... | ... | ... |
| 94031a | 2284 | " | " | Lever | ... | ... | ... | ... | ... |
| 94032 | 2114 | " | " | Lock Pin | ... | ... | ... | ... | ... |
| 94033b | 2114 | " | " | " | " | Head | ... | ... | ... |
| 55531 | 2114 | " | " | " | " | Spring | ... | ... | ... |
| 94034b | - | Crank , complete, Nos. 94028, 94029b, 94030b and 94031a | ... | ... | ... | ... | ... | ... | ... |
| 94046 | 2114 | Driver | ... | ... | ... | ... | ... | ... | ... |
| 94070 | - | " | 94046 with 80028 and 94048 | ... | ... | ... | ... | ... | ... |
| 94036 | 2114 | " | " | Finger | ... | ... | ... | ... | ... |
| 94039 | 2114 | " | " | Driving Pad (raw-hide) | ... | ... | ... | ... | ... |
| 94040 | 2114 | " | " | " | " | Plate | ... | ... | ... |
| SS567e | 2114 | " | " | " | " | and Plate Binding Screw | ... | ... | ... |
| 94041 | - | " | " | 94036 with SS567e, 94039 and 94040 | ... | ... | ... | ... | ... |
| 94044 | 2114 | " | " | " | " | Hinge Pin | ... | ... | ... |
| 94037 | 2114 | " | " | " | " | Latch | ... | ... | ... |
| SS565e | 2114 | " | " | " | " | Screw Stud | ... | ... | ... |
| 94038 | 2114 | " | " | " | " | Spring | ... | ... | ... |
| 94051b | 2284 | Gear with 55531, 94032 and 94033b | ... | ... | ... | ... | ... | ... | ... |
| 94016 | 2284 | " | " | Cover | ... | ... | ... | ... | ... |
| 399a | 2114 | " | " | " | " | Screw | ... | ... | ... |
| SS599f | 2114 | " | " | " | " | Screw Stud | ... | ... | ... |
| 94048 | 2114 | Pinion | ... | ... | ... | ... | ... | ... | ... |
| 80028 | 2114 | " | " | " | " | Dowel Pin | ... | ... | ... |
| SS600f | 2114 | " | " | " | " | Screw Stud (eccentric) | ... | ... | ... |
| 94052b | 2284 | Hand Attachment , complete, Nos. SS565e, SS566e, SS599f, SS600f, 94016, 94027, 94034b, 94037, 94038, 94041, 94044, 94050, 94051b, 94069, 94070, two each 183e and 399a | ... | ... | ... | ... | ... | ... | ... |
| SS566e | 2114 | Hand Attachment Screw | ... | ... | ... | ... | ... | ... | ... |

Obsolete Parts

| No. | Plate | | | | | | | | |
|-------|-------|---|-----|--------------------|------------------------------------|-----------|-----|-----|-----|
| 25361 | 1950 | Feed Bar Throw-out Lever with 1813 | ... | ... | ... | ... | ... | ... | ... |
| 25347 | 1950 | Feed Lifting Rock Shaft Crank with 157j | ... | ... | ... | ... | ... | ... | ... |
| 25362 | - | Feed Lifting Rock Shaft Crank , complete, Nos. 51289j, 125347 and 125361 | ... | ... | ... | ... | ... | ... | ... |
| 25267 | - | Feed Lifting Rock Shaft , complete, Nos. 125263, 125349 and 125362 | ... | ... | ... | ... | ... | ... | ... |
| 25268 | 1950 | Feed Regulator | ... | ... | ... | ... | ... | ... | ... |
| 25341 | - | " | " | 125268 with 125345 | ... | ... | ... | ... | ... |
| 25269 | 1950 | Feed Reversing Lever | ... | ... | ... | ... | ... | ... | ... |
| 25345 | - | " | " | " | 125269 with 1735j | ... | ... | ... | ... |
| 1735j | 1958 | " | " | " | Lock Nut | ... | ... | ... | ... |
| 5374 | - | Stitch Indicator Plate | ... | ... | ... | ... | ... | ... | ... |
| 5307 | 1950 | " | " | " | 125374 with 125309 | ... | ... | ... | ... |
| 5379 | - | " | " | " | 125307 with 711b, 38391 and 125308 | ... | ... | ... | ... |
| 5308 | 1950 | " | " | " | Cover | ... | ... | ... | ... |
| 335b | 1957 | " | " | " | " | Screw (2) | ... | ... | ... |
| 714b | 1958 | " | " | " | Regulating Thumb Screw | ... | ... | ... | ... |
| 5309 | - | " | " | " | " | Bushing | ... | ... | ... |
| 8391 | 1950 | " | " | " | " | Washer | ... | ... | ... |

Numerical List of Parts

| No. | Plate | |
|-------|-------|---|
| NN95j | 2399 | Embroidery Hoop Clamping Bracket Screw Nut for 96417 to 96421, 96423 and 96424 10/353, 10/355, |
| 138c | 1957 | Arm Screw ... 10/357, 10/361, 10/363. |
| 145j | 1957 | Shuttle Race Screw ... |
| 157j | 1957 | Feed Lifting Rock Shaft Crank Clamping Screw for 125347 and 125388 ... |
| 158c | 1957 | Bobbin Winder Bracket Screw ... |
| 175j | 1957 | Feed Forked Connection Adjusting Screw for 125262 ... |
| 183c | 2114 | Hand Attachment Body Bracket Screw for 94052b ... |
| 190b | 1957 | Bobbin Winder Tripping Arm Screw for 125327 and 193644 ... |
| 190b | 1957 | Face Plate Screw ... |
| 193b | 1957 | Bobbin Winder Tension Bracket Screw ... |
| 208al | 1957 | Feed Dog Screw ... |
| 224b | 4959 | Motor Cover Screw for 15K91 Machine ... |
| 246a | 2091 | Clamp Stop Motion Clamp Stop Screw for 15K91 Machine ... |
| 248a | 1957 | Clamp Stop Motion Clamp Stop Screw for 15314 ... |
| 256b | 1957 | Clamp Stop Motion Clamp Screw for 15314 |
| 304c | 1957 | Feed Lifting Rock Shaft Screw Centre for 125344 ... |
| 304c | 1957 | Feed Rock Shaft Screw Centre for 125344 ... |
| 315c | 1957 | Feed Bar Screw Centre ... |
| 335b | 1957 | Stitch Indicator Plate Cover Screw (Obsolete) |
| 335b | 1957 | Stitch Indicator Plate Screw ... |
| 375c | 1957 | Crank Connecting Rod Hinge Screw ... |
| 391j | 1957 | Shuttle Bobbin Case Position Plate Screw for 125300 ... |
| 399a | 2114 | Hand Attachment Gear Cover Screw for 94052b ... |
| 435c | 1957 | Arm Shaft Bushing Set Screw for 125252 ... |
| 447c | 4959 | Armature Shaft Bearing Sleeve (commutator end) Set Screw for 193545 ... |
| 447c | 4959 | Armature Shaft Bearing Sleeve (front end) Set Screw for 193545 ... |
| 448c | 1957 | Presser Bar Lifter Hinge Stud Set Screw for 125252 ... |
| 453c | 1957 | Presser Bar Spring Bracket Set Screw for 2068 ... |
| 462al | 1957 | Armature Shaft Pinion Set Screw for 193529 |
| 462al | 1957 | Clamp Stop Motion Flanged Bushing Set Screw for 15313 and 125372 ... |

| No. | Plate | |
|--------|-------|---|
| 462al | 1957 | Oscillating Shaft Crank Set Screw for 125283 and 125284 |
| SS528j | 2399 | Embroidery Hoop Clamping Bracket Screw for 96417 to 96421, 96423 and 96424 10/34 10 |
| SS565c | 2114 | Hand Attachment Driver Finger Latch Screw Stud for 94052b 10/35 11 |
| SS566c | 2114 | Hand Attachment Screw for 94052b 10/35 11 |
| SS567c | 2114 | Hand Attachment Driver Finger Driving Pad and Plate Binding Screw for 94041 10/35 11 |
| 570c | 1957 | Needle Bar Connecting Link Hinge Screw for 15434 |
| 591f | 1957 | Shuttle Tension Regulating Screw for 125291 |
| 592c | 1957 | Shuttle Bobbin Case Latch Stop Screw for 125291 |
| SS599f | 2114 | Hand Attachment Gear Screw Stud for 94052b |
| SS600f | 2114 | Hand Attachment Pinion Screw Stud (eccentric) for 94052b |
| 662j | 1957 | Shuttle Race Cap Screw for 125304 |
| 691a | 1957 | Throat Plate Screw |
| 714b | 1958 | Stitch Regulating Thumb Screw for 125379 (Obsolete) |
| 857b | 1957 | Thread Take-up Spring Regulator Set Screw for 125368 |
| 882e | 4959 | Brush Tube Insulating Bushing Set Screw for 193545 |
| 896e | 1957 | Crank Connecting Rod Cap Screw for 125021 |
| 1085e | 1957 | Feed Forked Connection Slide Block Screw Stud for 125335 |
| 1253c | 1957 | Shuttle Driver Set Screw for 125297 |
| 1285c | 1957 | Feed Cam and Counterbalance Position Screw for 125045 |
| 1293al | 1957 | Thread Take-up Cam Timing Screw for 15272 |
| 1341c | 1958 | Needle Bar Connecting Stud Set Screw for 125276 |
| 1498c | 1958 | Needle Bar Bushing Set Screw |
| 1513j | 1958 | Feed Lifting Rock Shaft Screw Centre Nut for 125344 |
| 1513j | 1958 | Feed Rock Shaft Screw Centre Nut for 125344 |
| 1518j | 1958 | Crank Connecting Rod Hinge Screw Nut |
| 1519j | 1958 | Feed Bar Screw Centre Nut |
| 1520j | 1958 | Feed Forked Connection Hinge Screw Nut |
| 1520j | 1958 | Needle Bar Connecting Link Hinge Screw Nut for 15434 |
| 1550j | 1960 | Feed Reversing Handle Lock Nut for 125381 |
| 1735j | 1958 | Feed Reversing Lever Lock Nut for 125345 (Obsolete) |

| No. | Plate | |
|--------|-------|--|
| 1768r | 4959 | Three-Pin Terminal (female half) Housing Screw Nut for 192989 |
| 1813 | 1958 | Feed Throw-out Lever Roller and Stud for 125361 and 125386 |
| 1822 | 1958 | Thread Take-up Lever Roller and Stud for 125382 |
| 2002 | 1954 | Arm Dowel Pin |
| 2007 | 1954 | Arm Spool Pin |
| 2007 | 1954 | Bobbin Winder Spool Pin |
| 2020 | 1954 | Clamp Stop Motion Clamp Washer for 15314 |
| 2022 | 2552 | Clamp Stop Motion Flanged Bushing Pin |
| 2049 | 2552 | Oscillating Shaft Crank Pin for 125363 |
| 2049 | 2552 | Shuttle Driver Pin |
| 2068 | 2552 | Presser Bar Spring Bracket with 453c |
| 2070 | 2552 | Presser Bar Spring Washer |
| 2102 | 2552 | Tension Disc for 125418 |
| 2518 | 1954 | Shuttle Bobbin for 125294 |
| 2835 | 792 | Feed Bar |
| 2974 | 1954 | Shuttle Bobbin Case Latch Lever Fulcrum Pin for 125288 |
| 2975 | 1954 | Shuttle Bobbin Case Latch Spring for 125291 |
| 2971 | 1955 | Bobbin Winder Tension Bracket Screw Washer |
| 2879 | 2574 | Spool Pin Washer (cloth) for 160810 and 160811 |
| 15072 | 1954 | Bobbin Winder Bobbin Position Pin for 125068 |
| *15170 | 2552 | Oscillating Shaft Crank Slide Block for 125330 |
| *15248 | 1954 | Needle Bar Connecting Link with 51002e, for 125275 |
| 15272 | 1954 | Thread Take-up Cam with 1293al, for 15434 |
| 15282 | 1152 | Hand Wheel, 2 1/4" pulley, for 15K88 and 15K89 Machines |
| 15287 | 1955 | Bobbin Winder Friction Ring (rubber) for 125327 and 15K91 Machine |
| 15288 | 1955 | Bobbin Winder Pulley for 125366 |
| *15312 | --- | Clamp Stop Motion Flanged Bushing for 15313 |
| 15313 | 1954 | Clamp Stop Motion Flanged Bushing 15312 with two 462al, for 15314 |
| 15314 | --- | Clamp Stop Motion, complete, Nos. 248a, 256b, 2020 and 15313, for 15K88 to 15K90 Machines |
| 15110 | 2552 | Tension Stud Bushing for 125384 |
| *15134 | --- | Thread Take-up Cam 15272, with 570c and 1520j, for 125254 |

| No. | Plate | |
|-------------------|-----------------|---|
| 15486 | 2552 | Presser Bar Lifter Hinge Stud for 125252 ... |
| 15498 | 1954 | Arm Shaft Bushing for 125252 and 125254 |
| 25525 | 2719 | Bias Gauge |
| 25527b | 2719 | Cloth Guide |
| 25537 | 2574 | Screw Driver (machine) for 160810 and 160811 (Accessories) |
| 25539 | 2719 | Stiletto |
| 26075 | 2552 | Thread Cutter and Holder |
| 32519 | 1954 | Needle Stop Pin for 125377 |
| 32672 | 1722 | Hand Wheel, 3 1/2" Pulley, for 15K90 Machine |
| *32774 | | Presser Foot Shank for 45321 |
| 35931 | 2574 | Hemmer (adjustable) for 160810 and 160811 |
| 35932 | 2719 | Quilter |
| 36583 | 1956 | Tucker |
| 36865 | 2574 | Edge Stitcher for 160810 and 160811 |
| 38391 | 1950 | Stitch Regulating Thumb Screw Washer for 125379 (Obsolete) |
| 45285 | 1951 | Needle Clamp 45331 with 51308j |
| *45290 | | Stitch Regulating Thumb Screw Bushing for 45308 |
| 45305 | 1960 | Feed Reversing Handle for 125381 |
| 45306 | 1960 | Stitch Indicator Plate for 45309 |
| 45307 | | Stitch Regulating Plate for 45309 |
| 45308 | 1960 | Stitch Regulating Plate 45307 with 45289 for 45309 |
| 45309 | | Stitch Regulating Plate 45308 with 45306, 45310, 51312b and 125400 |
| 45310 | 1960 | Stitch Regulating Thumb Screw Washer (fibre) for 45309 |
| 45319 | | Presser Foot Plate for 45321 |
| 45321 | 1951 | Presser Foot (hinged), complete, Nos. 32774, 45319, and 45329 |
| 45329 | | Presser Foot Hinge Pin for 45321 |
| 45334 | | Needle Clamp with 140545c for 45285 |
| 45339 | 2391 | Tension Regulating Thumb Nut Engaging Pin for 51682 |
| 45847 | 1955 | Bobbin Winder Tension Disc Spring for 125396 |
| 45865 | 2391 | Tension Indicator Flange Stop Washer for 125418 |
| 45915 | 1955 | Bobbin Winder Tension Disc for 125396 |
| 45916 | 1955 | Bobbin Winder Tension Disc Screw Washer for 125396 |
| 50053b | 2719 | Cloth Guide and Under Braider Thumb Screw |
| 50292b | 1957 | Tension Stud Set Screw for 125368 |
| 50353c | 1957 | Feed Regulator Hinge Screw |

| No. | Plate | |
|---------|-------|--|
| 50527c | 1957 | Thread Take-up Lever Hinge Screw for 125383 |
| 50617b | 1959 | Armature Shaft Bearing Sleeve (front end) Cap Screw for 15K91 Machine |
| 50657r | 4964 | Three-Pin Terminal Body (male half) Screw for 15K91 Machine |
| 51002c | 1957 | Needle Bar Connecting Link Adjusting Screw for 15248 |
| 51045c | 1958 | Machine Hinge Connection Set Screw |
| 51093r | 2091 | Three-Pin Terminal (female half) Housing Screw for 192989 |
| 51221b | 1957 | Arm Side Cover Thumb Screw |
| 51224b | 1957 | Presser Foot Thumb Screw |
| *51228b | 2552 | Pressure Regulating Thumb Screw for 66773 |
| 51229c | 1958 | Shuttle Driver Cushion Spring Screw for 125322 and 125323 |
| 51246c | 1958 | Oscillating Rock Shaft Centre (left) Set Screw |
| 51246c | 1958 | Oscillating Rock Shaft Centre (right) Set Screw |
| 51252c | 1958 | Feed Forked Connection Hinge Screw (eccentric) |
| 51261j | 1958 | Shuttle Race Back Spring Thumb Screw for 125306 |
| 51280b | 2091 | Clamp Stop Motion Clamp Screw for 125371 |
| 51281c | 1956 | Hand Wheel Gear Collar Set Screw for 125353 |
| 51282j | 1958 | Shuttle Race Slide Spring Screw for 125338 |
| 51284r | 1959 | Grease Wick Spring Cap Screw for 15K91 Machine |
| 51285c | 1959 | Motor Frame Screw for 15K91 Machine |
| 51286r | 1959 | Field Core Screw for 15K91 Machine |
| 51289j | 1958 | Feed Throw out Lever Thumb Screw for 125362 and 125389 |
| 51293c | 4964 | Three-Pin Terminal Body (male half) Bracket Screw for 15K91 Machine |
| 51303b | 1955 | Bobbin Winder Stop Latch Hinge Screw for 125327 and 193644 |
| 51308j | 1958 | Needle Clamp Position Screw for 45285 |
| 51312b | 1960 | Stitch Regulating Thumb Screw for 45309 |
| 51319b | 2091 | Bobbin Winder Frame Hinge Screw for 125327 and 193644 |
| 51582b | 2091 | Three-Pin Terminal Body (male half) Post Thumb Nut for 192797 |
| 51682b | 2391 | Tension Regulating Thumb Nut with 45339 for 125420 |

| No. | Plate | |
|-------|-------|--|
| 55531 | 2114 | Hand Attachment Crank Lever Lock Pin Spring for 94051b |
| 55621 | 1951 | Presser Bar Lifter |
| 66601 | 1955 | Bobbin Winder Frame Spring for 125327 ... |
| 66670 | 1955 | Bobbin Winder Frame for 125366 ... |
| 66752 | 2552 | Pressure Regulating Thumb Screw Plug (felt) for 66773 |
| 66773 | — | Pressure Regulating Thumb Screw 51228b with 66752 |

| No. | Plate | |
|-------|-------|---|
| 80011 | 2391 | Presser Bar Spring |
| 80028 | 2114 | Hand Attachment Pinion Dowel Pin for 94070 |
| 85893 | 1956 | Embroidery Foot (for art work) |
| 86642 | 2574 | Ruffler for 160810 and 160811 |
| 87586 | — | Embroidery Hoop (round, birch) 5 $\frac{3}{8}$ " diam. $\times 7\frac{m}{m}$ high <i>10/1336 & 10/1337</i> ... |
| 87589 | 1221 | Embroidery Hoop (round, birch) 8" diam. $\times 7\frac{m}{m}$ high <i>10/1338 & 10/1339</i> ... |
| 87593 | — | Embroidery Hoop (round, birch) 10" diam. $\times 7\frac{m}{m}$ high <i>10/1340 & 10/1341</i> ... |
| 87595 | — | Embroidery Hoop (round, birch) 12" diam. $\times 7\frac{m}{m}$ high <i>10/1342 & 10/1343</i> ... |
| 87597 | — | Embroidery Hoop (oval, birch) 12" \times 5 $\frac{1}{2}$ " \times $7\frac{m}{m}$ high <i>10/1344 & 10/1345</i> ... |

| No. | Plate | |
|--------|-------|---|
| 94016 | 2284 | Hand Attachment Gear Cover for 94052b ... |
| 94027 | 2284 | Hand Attachment Body Bracket for 94052b |
| 94028 | 2114 | Hand Attachment Crank Handle (wood) for 94034b |
| 94029b | 2114 | Hand Attachment Crank Handle Spindle for 94034b |
| 94030b | 2114 | Hand Attachment Crank Handle Spindle Flange (loose) for 94034b |
| 94031a | 2284 | Hand Attachment Crank Lever for 94034b ... |
| 94032 | 2114 | Hand Attachment Crank Lever Lock Pin for 94051b |
| 94033b | 2114 | Hand Attachment Crank Lever Lock Pin Head for 94051b |
| 94034b | | Hand Attachment Crank, complete, Nos. 94028, 94029b, 94030b and 94031a, for 94052b |
| 94036 | 2114 | Hand Attachment Driver Finger for 94041 |
| 94037 | 2114 | Hand Attachment Driver Finger Latch for 94052b |
| 94038 | 2114 | Hand Attachment Driver Finger Latch Spring for 94052b |
| 94039 | 2114 | Hand Attachment Driver Finger Driving Pad (raw-hide) for 94041 |
| 94040 | 2114 | Hand Attachment Driver Finger Driving Pad Plate for 94041 |
| 94041 | - | Hand Attachment Driver Finger 94036, with SS567c, 94039 and 94040, for 94052b ... |
| 94044 | 2114 | Hand Attachment Driver Finger Hinge Pin for 94052b |
| 94046 | 2114 | Hand Attachment Driver for 94070 ... |
| 94048 | 2114 | Hand Attachment Pinion for 94070 ... |
| 94050 | 2284 | Hand Attachment Body for 94052b ... |
| 94051b | 2284 | Hand Attachment Gear with SS531, 94032 and 94033b, for 94052b |
| 94052b | 2284 | Hand Attachment, complete Nos. SS565c, SS566c, SS599f, SS600f, 94016, 94027, 94034b, 94037, 94038, 94041, 94044, 94050, 94051b, 94069, 94070, two each 183c and 399a |
| 94069 | 2114 | Hand Attachment Crank Hinge Pin for 94052b |
| 94070 | - | Hand Attachment Driver 94046 with 80028 and 94048, for 94052b |

| | | |
|-------|------|---|
| 96416 | - | Embroidery Hoop (round, birch) 7" diam. x 7 ^m / _m high 101346, 101347 ... |
| 96417 | - | Embroidery Hoop (round, birch) 5 ^g / _m diam. x 7 ^m / _m high, with SS528j, NN95j, two 96425 and four 96427 |
| 96418 | - | Embroidery Hoop (round, birch) 7" diam. x 7 ^m / _m high, with SS528j, NN95j, two 96426 and four 96427 |
| 96419 | - | Embroidery Hoop (round, birch) 8" diam. x 7 ^m / _m high, with SS528j, NN95j, two 96426 and four 96427 |
| 96420 | - | Embroidery Hoop (round, birch) 10" diam. x 7 ^m / _m high, with SS528j, NN95j, two 96426 and four 96427 |
| 96421 | - | Embroidery Hoop (round, birch) 12" diam. x 7 ^m / _m high, with SS528j, NN95j, two 96844 and four 96845 |
| 96422 | 1221 | Embroidery Hoop (oval, birch) 9" x 4 ¹ / ₂ " x 7 ^m / _m high 101358, 101359 ... |
| 96423 | - | Embroidery Hoop (oval, birch) 9" x 4 ¹ / ₂ " x 7 ^m / _m high, with SS528j, NN95j, 96425, 96426 and four 96127 |
| 96424 | - | Embroidery Hoop (oval, birch) 12" x 5 ^g / _m x 7 ^m / _m high, with SS528j, NN95j, 96425, 96426 and four 96427 |
| 96425 | 2399 | Embroidery Hoop Clamping Bracket for 101349, 101361, 10117, 96428 and 96424 ... 101363. |
| 96426 | 2399 | Embroidery Hoop Clamping Bracket for 101351, 101353, 10118 to 96420, 96423 and 96424 101355, 101361, 101363 |
| 96427 | 2399 | Embroidery Hoop Clamping Bracket Rivet for 96417 to 96420, 96423 and 96424 101349, 101351, |
| 96844 | 2399 | Embroidery Hoop Clamping Bracket for 101353, 101355, 96421 101357 ... 101361, 101362 |
| 96845 | 2399 | Embroidery Hoop Clamping Bracket Rivet for 96421 101357 |
| 97382 | 2090 | Bayonet Plug, complete, Nos. 97383 and 97384, for 15K91 Machine |
| 97383 | 2090 | Bayonet Plug Body for 97382 |
| 97384 | 2090 | Bayonet Plug Cover for 97382 |
| 96417 | - | Embroidery Hoop (round, birch) 5 ^g / _m diam. x 7 ^m / _m high, complete, Nos. 101348 and 101349 |
| 96418 | 2193 | Embroidery Hoop (round, birch) 7" diam. x 7 ^m / _m high, complete, Nos. 101350 and 101351 |
| 96419 | - | Embroidery Hoop (round, birch) 8" diam. x 7 ^m / _m high, complete, Nos. 101352 and 101353 |
| 96420 | - | Embroidery Hoop (round, birch) 10" diam. x 7 ^m / _m high, complete, Nos. 101354 and 101355 |
| 96421 | - | Embroidery Hoop (round, birch) 12" diam. x 7 ^m / _m high, complete, Nos. 101356 and 101357 |
| 96423 | - | Embroidery Hoop (oval, birch) 9" x 4 ¹ / ₂ " x 7 ^m / _m high, complete, Nos. 101360 and 101361 |
| 96424 | - | Embroidery Hoop (oval, birch) 12" x 5 ^g / _m 7 ^m / _m high, complete, Nos. 101362 and 101363 |

| | | | |
|--------|---|--|--------|
| 101362 | — | Embroidery Hoop (inner) for 96424 | ... |
| 101363 | — | Embroidery Hoop (outer) with SS528j, NN95j, 96425, 96426 and four 96427, for 96424 | |
| 101364 | — | Embroidery Hoop (inner) for 101246 | ... |
| 101365 | — | Embroidery Hoop (outer) with Spring, for 101246 | |
| 140728 | — | Presser Foot Adjusting Thumb Screw for 161127 | |
| 161122 | — | Presser Foot Adjusting Thumb Screw Spring for 161127 | |
| 161123 | — | Presser Foot Hinge Pin for 161127 | ... |
| 161124 | — | Presser Foot Plate for 161127 | ... |
| 161125 | — | Presser Foot Shank (adjustable) for 161127 | ... |
| 161126 | — | Presser Foot Shank (stationary) for 161127 | ... |
| 161127 | — | Presser Foot (hinged, adjustable) for sewing on the right or left side of the needle, complete, Nos. 140728 and 161122 to 161126 | |
| 101246 | — | Embroidery Hoop (round, birch) 10" diam. x $\frac{7}{16}$ " high, complete, Nos. 101364 and 101365 | |
| 101336 | — | Embroidery Hoop (inner) for 87586 | ... |
| 101337 | — | Embroidery Hoop (outer) for 87586 | ... |
| 101338 | — | Embroidery Hoop (inner) for 87589 | ... |
| 101339 | — | Embroidery Hoop (outer) for 87589 | ... |
| 101340 | — | Embroidery Hoop (inner) for 87593 | ... |
| 101341 | — | Embroidery Hoop (outer) for 87593 | ... |
| 101342 | — | Embroidery Hoop (inner) for 87595 | ... |
| 101343 | — | Embroidery Hoop (outer) for 87595 | ... |
| 101344 | — | Embroidery Hoop (inner) for 87597 | ... |
| 101345 | — | Embroidery Hoop (outer) for 87597 | ... |
| 101346 | — | Embroidery Hoop (inner) for 96416 | ... |
| 101347 | — | Embroidery Hoop (outer) for 96416 | ... |
| 101348 | — | Embroidery Hoop (inner) for 96417 | ... |
| 101349 | — | Embroidery Hoop (outer) with SS528j, NN95j, two 96425 and four 96427, for 96417 | |
| 101350 | — | Embroidery Hoop (inner) for 96418 | ... |
| 101351 | — | Embroidery Hoop (outer) with SS528j, NN95j, two 96426 and four 96427, for 96418 | |
| 101352 | — | Embroidery Hoop (inner) for 96419 | ... |
| 101353 | — | Embroidery Hoop (outer) with SS528j, NN95j, two 96426 and four 96427, for 96419 | |
| 101354 | — | Embroidery Hoop (inner) for 96420 | ... |
| 101355 | — | Embroidery Hoop (outer) with SS528j, NN95j, two 96426 and four 96427, for 96420 | |
| 101356 | — | Embroidery Hoop (inner) for 96421 | ... |
| 101357 | — | Embroidery Hoop (outer) with SS528j, NN95j, two 96844 and four 96845, for 96421 | |
| 101358 | — | Embroidery Hoop (inner) for 96422 | ... |
| 101359 | — | Embroidery Hoop (outer) for 96422 | ... |
| 101360 | — | Embroidery Hoop (inner) for 96423 | ... |

NUMERICAL LIST OF PARTS

87

| No. | Plate | |
|---------|-------|---|
| 120378 | 2574 | Screw Driver (bobbin case) for 160810 and 160811 |
| 120687 | 1956 | Imitation Hemstitching Attachment with yielding presser plate |
| 120855 | 1946 | Hemmer (foot), $\frac{5}{16}$ " hem... |
| 120861 | | Tin of Oil (3 oz.) |
| 120914 | 1946 | Peller (foot) |
| 121094 | 2719 | Darning Foot (spring) |
| 121170 | 909 | Ruffler Shirring Plate |
| 121441 | 2574 | Gathering Foot (double toe) for 160810 and 160811 |
| 121441 | 2574 | Presser Foot (double toe) for gathering |
| 121464 | 2574 | Binder for 160810 and 160811 |
| 121547 | 909 | Under Braider |
| 121875 | | Presser Foot for 121877 <i>obsolete</i> |
| 121876 | | Presser Foot Body for 121877 <i>obsolete</i> |
| 121877 | 2719 | Presser Foot (adjustable for sewing on the right or left side of the needle), complete, Nos. 121875, 121876 and 140347w, for Cording and Slide Fastener Work <i>obsolete use 161127</i> |
| *125012 | | Crank Connecting Rod Cap for 125021 |
| 125021 | 1947 | Crank Connecting Rod with 125012, 125044 and two 896e |
| 125029 | | Drip Pan (for Cover Set) |
| 125044 | 1949 | Crank Connecting Rod Oil Pad (felt) for 125021 |
| 125045 | 2552 | Feed Cam and Counterbalance with 1285c, for 125251 |
| 125047 | 2552 | Feed Forked Connection Slide Block for 125335 |
| 125048 | 2552 | Oscillating Rock Shaft Centre (left) |
| 125049 | 2552 | Oscillating Rock Shaft Centre (right) |
| 125056 | 1949 | Oscillating Rock Shaft Oil Wick (braided cotton) for 125280 |
| *125060 | 2552 | Oscillating Shaft Crank Slide Block Stud for 125330 |
| 125061 | 2552 | Presser Bar |
| 125068 | 1955 | Bobbin Winder Spindle with 15072, for 125366 |
| *125251 | | Arm for 125252 |
| 125252 | | Arm 125251 with 135c, 148c, 15486 and 15498 |
| 125253 | 1947 | Arm Shaft for 125254 |
| *125254 | | Arm Shaft 125253 with 15434, 15498 and 125045 |
| *125255 | | Bed |
| 125258 | 1951 | Face Plate Tension Seat for 125384 |
| 125261 | 1946 | Feed Dog, 12 teeth (14 teeth to the inch) |

| No. | Plate | |
|---------|-------|--|
| 125262 | 1947 | Feed Forked Connection with 175j, for 125340 |
| 125263 | 1947 | Feed Lifting Rock Shaft for 125267 and 125390 |
| 125267 | -- | Feed Lifting Rock Shaft, complete, Nos. 125263, 125349 and 125362 (Obsolete) |
| 125268 | 1950 | Feed Regulator for 125341 (Obsolete) |
| 125269 | 1950 | Feed Reversing Lever for 125345 (Obsolete) |
| 125270 | 1947 | Feed Rock Shaft |
| *125272 | 1951 | Needle Bar Bushing for 125273 |
| 125273 | — | Needle Bar Bushing 125272 with 125274 |
| 125274 | 1949 | Needle Bar Bushing Oil Pad (felt) for 125273 |
| 125275 | — | Needle Bar Connecting Link 15248 with 125276 |
| 125276 | 1950 | Needle Bar Connecting Stud with 1341c, for 125275 |
| 125280 | 1947 | Oscillating Rock Shaft with 125056 |
| 125281 | 2551 | Oscillating Shaft for 125363 |
| *125282 | — | Oscillating Shaft Crank for 125283 and 125284 |
| *125283 | 1950 | Oscillating Shaft Crank 125282, with 462al and 125330 for 125323 |
| 125284 | — | Oscillating Shaft Crank 125282 with 125330 and two 462al |
| 125285 | 1946 | Presser Foot |
| 125287 | 1949 | Shuttle Bobbin Case Latch for 125288 |
| 125288 | — | Shuttle Bobbin Case Hinge, Nos. 2974, 125287 and 125320 for 125291 |
| 125290 | 1948 | Shuttle Bobbin Case Position Plate for 125300 |
| 125291 | 1949 | Shuttle Bobbin Case with 591f, 592c, 2975, 125288 and 125293, for 125291 |
| 125292 | 1949 | Shuttle Body for 125294 |
| 125293 | 1949 | Shuttle Tension Spring for 125291 |
| 125294 | — | Shuttle, 1 $\frac{11}{16}$ " diam., complete, Nos. 2518, 125291 and 125292 |
| *125295 | 1949 | Shuttle Driver for 125297 and 125363 |
| 125297 | — | Shuttle Driver 125295, with two 1253c, for 125322 |
| 125298 | 1949 | Shuttle Driver Cushion Spring for 125322 and 125323 |
| 125299 | 1948 | Shuttle Race Back for 125306 |
| 125300 | — | Shuttle Race Body 125304, with 125290, two each 391j and 125301, for 125306 |
| 125301 | 1949 | Shuttle Race Back Position Pin for 125300 |
| 125302 | 1948 | Shuttle Race Back Spring for 125306 |
| 125303 | 1948 | Shuttle Race Body for 125304 |
| 125304 | — | Shuttle Race Body 125303 with 125305 and two 662j, for 125300 |

| No. | Plate | |
|---------|-------|--|
| 125305 | 1948 | Shuttle Race Cap for 125301 |
| 125306 | — | Shuttle Race, complete, Nos. 51261j, 125299, 125300 and 125302 |
| 125307 | 1950 | Stitch Indicator Plate 125374, with 125309, for 125379 (Obsolete) |
| 125308 | 1950 | Stitch Indicator Plate Cover for 125379 (Obsolete) |
| *125309 | — | Stitch Regulating Thumb Screw Bushing for 125307 (Obsolete) |
| 125314 | 2391 | Tension Spring for 125418 |
| 125316 | 2391 | Thread Take-up Spring for 125418 |
| 125317 | 1951 | Thread Take-up Spring Regulator for 125368 |
| 125319 | 1946 | Throat Plate for 125261 |
| 125320 | 1949 | Shuttle Bobbin Case Latch Lever for 125283 |
| 125322 | 1919 | Shuttle Driver 125297 with 125298 and two 51229c |
| 125323 | — | Oscillating Shaft 125363 with 125283, 125298 and two 51229c |
| †125324 | 1955 | Bobbin Winder Bracket (belt cover) for 125327 |
| 125326 | 1955 | Bobbin Winder Tripping Arm for 125327 and 193614 |
| †125327 | 1955 | Bobbin Winder (automatic), complete, Nos. 190b, 15287, 51303b, 51319b, 66601, 125324, 125326, 125366, 125376 and 125462 for Hand Wheel No. 15282 or No. 32672 |
| 125330 | — | Oscillating Shaft Crank Slide Block 15170, with 125060, for 125283 and 125284 |
| 125331 | 1919 | Arm Oil Pad (felt) for oiling Arm Shaft Back Bearing |
| 125333 | 1919 | Arm Oil Pad Spring |
| 125331 | 1949 | Arm Oil Pad Spring Cap |
| 125335 | — | Feed Forked Connection Slide Block 125047 with 1085c, for 125340 |
| 125336 | 1946 | Shuttle Race Slide for 125338 |
| 125337 | 1946 | Shuttle Race Slide Spring for 125338 |
| 125338 | — | Shuttle Race Slide, complete, Nos. 125336, 125337 and two 51282j |

† In ordering it is necessary to state Class of Machine.

| | | |
|--------|---|---|
| 125340 | — | Feed Forked Connection 125262 with 125335 |
| 125341 | — | Feed Regulator 125268 with 125345 (Obsolete) |
| 125344 | — | Feed Lifting Rock Shaft Screw Centre 301c with 1513j |
| 125344 | — | Feed Rock Shaft Screw Centre 301c with 1513j |

| No. | Plate | |
|---------|-------|--|
| 125345 | - | Feed Reversing Lever 125269, with 1735j, for 125341 ... (Obsolete) |
| 125347 | 1950 | Feed Lifting Rock Shaft Crank with 157j, for 125362 ... (Obsolete) |
| 125349 | 1950 | Feed Throw-out Lever Retaining Ring for 125267 and 125390 ... |
| 125350 | 1960 | Hand Wheel with 125358, for 125364 ... |
| 125351 | - | Hand Wheel Gear (textolite) for 125352 |
| 125352 | 1956 | Hand Wheel Gear 125351, with 125356 and 125357, for 125364 ... |
| 125353 | 1956 | Hand Wheel Gear Collar with three 51281c, for 125364 ... |
| 125354 | 1956 | Hand Wheel Gear Spring for 125364 ... |
| 125355 | 1956 | Hand Wheel Gear Spring Retaining Washer for 125364 ... |
| 125356 | 1956 | Hand Wheel Gear Spring Stud for 125352 ... |
| 125357 | 1956 | Hand Wheel Gear Spring Stud Washer for 125352 ... |
| 125358 | 1956 | Hand Wheel Spring Stud for 125350 ... |
| 125359 | 2091 | Clamp Stop Motion Clamp Washer for 15K91 Machine ... |
| 125360 | 1949 | Clamp Stop Motion Flanged Bushing for 125371 and 125372 ... |
| 125361 | 1950 | Feed Bar Throw-out Lever with 1813, for 125362 ... (Obsolete) |
| 125362 | - | Feed Lifting Rock Shaft Crank, complete, Nos. 51289j, 125347 and 125361, for 125267 ... (Obsolete) |
| 125363 | - | Oscillating Shaft 125281 with 2019 and 125295 for 125323 ... |
| 125364 | - | Hand Wheel 125350 with 125352 to 125355 and two 125385 for 15K91 Machine ... |
| 125365 | 2091 | Bobbin Winder Frame Spring for 193644 ... |
| 125366 | - | Bobbin Winder Frame 66670, with 15288 and 125068 for 125327 and 193644 ... |
| *125367 | 2551 | Face Plate for 125381 ... |
| 125368 | - | Face Plate 125381, with 857b, 50292b and 125317, for 125412 ... |
| 125369 | 1950 | Face Plate Thread Guard 125428 with 125373, for 125384 ... |
| *125371 | - | Clamp Stop Motion Flanged Bushing 125360 with 51280b, for 15K91 Machine ... |
| 125372 | - | Clamp Stop Motion Flanged Bushing 125360 with two 462a1, for 15K91 Machine ... |
| 125373 | - | Face Plate Thread Guard Rivet for 125369 |
| 125374 | - | Stitch Indicator Plate for 125307 (Obsolete) |

| No. | Plate | |
|---------|-------|---|
| 125376 | 1955 | Bobbin Winder Stop Latch for 125327 and 193644 ... |
| 125377 | 1951 | Needle Bar with 32510 ... |
| 125378 | 1951 | Needle Clamp Gib and Thread Guard ... |
| 125379 | - | Stitch Indicator Plate 125307 with 714b, 38391 and 125308 ... (Obsolete) |
| 125381 | - | Feed Reversing Handle 45305 with 1550j, for 125398 ... |
| *125382 | 1951 | Thread Take-up Lever with 1822, for 125383 |
| 125383 | - | Thread Take-up Lever 125382 with 50527c |
| 125384 | - | Face Plate 125367, with 15410, 125258 and 125369, for 125368 ... |
| 125385 | 2091 | Hand Wheel Gear Spring Cushion Pin (eccentric) for 125364 ... |
| 125386 | 1960 | Feed Throw-out Lever with 1813, for 125389 |
| 125387 | 1960 | Feed Throw-out Lever Spring for 125389 ... |
| 125388 | 1960 | Feed Lifting Rock Shaft Crank with 157j, for 125389 ... |
| 125389 | - | Feed Lifting Rock Shaft Crank, complete, Nos. 51289j and 125386 to 125388, for 125390 ... |
| 125390 | - | Feed Lifting Rock Shaft, complete, Nos. 125263, 125349 and 125389 ... |
| 125395 | 1955 | Bobbin Winder Tension Bracket for 125396 |
| 125396 | - | Bobbin Winder Tension Bracket, complete, Nos. 45847, 45915, 45916, 125395 and 140138b ... |
| 125397 | 2391 | Feed Regulator for 125398 ... |
| 125398 | - | Feed Regulator 125397 with 125381 ... |
| 125399 | 2552 | Feed Regulator Hinge Screw Friction Washer |
| 125400 | 2391 | Stitch Regulating Thumb Screw Friction Washer for 45309 ... |
| 125412 | 2551 | Face Plate 125368 with 125418 ... |
| 125416 | 2391 | Tension Indicator Flange for 125418 ... |
| 125417 | 2391 | Tension Releasing Pin for 125418 ... |
| 125418 | - | Tension, complete, Nos. 45865, 125314, 125316, 125416, 125417, 125419 to 125421 and two 2102 for 125412 ... |
| 125419 | 2391 | Thread Take-up Spring Thread Guard for 125418 ... |
| 125420 | - | Tension Stud 140175e with 51682b for 125418 |
| 125421 | 2391 | Tension Indicator for 125418 ... |
| 125425b | 2391 | Arm Side Cover ... |
| 125428 | 2391 | Face Plate Thread Guard for 125369 ... |

| No. | Plate | |
|--------|-------|---|
| 125462 | 1955 | Bobbin Winder Stop Latch Spring for 125327 and 193644 |

| No. | Plate | |
|---------|-------|---|
| 140138b | 1955 | Bobbin Winder Tension Screw for 125396 ... |
| 140175e | 2391 | Tension Stud for 125420 |
| 140347w | 2719 | Presser Foot Adjusting Thumb Screw for 121877 <i>absolute</i> |
| 140545c | 1958 | Needle Clamp Thumb Screw for 45334 ... |

| | | |
|--------|------|--|
| 160810 | --- | Set of Attachments, complete, Nos. 25537, 35931, 36865, 86642, 120378, 121441, 121461, two 8879 and six needles ... |
| 160811 | --- | Set of Attachments (less needles), complete, Nos. 25537, 35931, 36865, 86642, 120378, 121441, 121464 and two 8879 |
| 160845 | 2719 | Cording Foot (left toe) for Stitching on Edge, Inserting Cord and Slide Fastener Work |
| 160846 | 2719 | Cording Foot (right toe) for Stitching on Edge, Inserting Cord and Slide Fastener Work |

| No. | Plate | |
|---------|-------|---|
| *190439 | — | Tube, filled with Singer Lubricant, for Electric Motors, for 190613 |
| 190612 | --- | Tube Carton (paper) for 190613 |
| 190613 | --- | Tube 190439 with 190612, for 15K91 Machine |
| 192348 | 1949 | Lead Bushing for 192875 |
| 192424 | 4959 | Field Coil Retainer for 15K91 Machine ... |
| 192457 | 4959 | Brush (carbon) for 50 to 145 volts, for 15K91 Machine |
| 192458 | 4959 | Brush Spring for 15K91 Machine |
| 192540 | --- | Screw Plug, complete, Nos. 192541 and 192542, for 15K91 Machine |
| 192541 | 2090 | Screw Plug Base for 192540 |
| 192542 | 2090 | Screw Plug with 192543, for 192540 |
| 192543 | 2090 | Screw Plug Flash Disc (tibre) for 192542 ... |
| *192642 | --- | Three-Pin Terminal Body (male half) for 193700 |
| *192643 | --- | Three-Pin Terminal (female half) Housing (upper) for 192989 |
| *192644 | --- | Three-Pin Terminal (female half) Housing (lower) for 192989 |
| 192691 | 2091 | Three-Pin Terminal (female half) Insert Sleeve for 192989 |
| 192692 | 2091 | Three-Pin Terminal (female half) Insert Clamp for 192989 |
| 192790 | 4959 | Three-Pin Terminal Adaptor Bushing for 192851 |
| 192793 | 2091 | Three-Pin Terminal Body (male half) Post for 193700 |
| 192797 | 4964 | Three-Pin Terminal Body (male half), complete, Nos. 193700, three each 51582 and 701719, for 15K91 Machine |
| *192820 | --- | Lead Cord, 8 ft. long, for 192875 |
| 192851 | --- | Lead Cord, complete, from lamp socket to three-pin terminal, for Knee and Treadle Control, Nos. 192790, 192852, 192989 and Plug for 15K91 Machine |
| *192852 | --- | Lead Cord for 192851 |
| 192874 | --- | Lead Cord, 3 ft. 10 ins. long, for 192875 ... |
| 192875 | --- | Lead Cord, complete, from lamp socket to three-pin terminal and controller, for Foot Controller, Nos. 192348, 192820, 192874, 192989, Plug and two 195834, for 15K91 Machine |

| No. | Plate | |
|---------|-------|--|
| 192989 | 4964 | Three-Pin Terminal (female half), complete, Nos. 192643, 192644, two each 1768r, 51093r, three each 192691 and 192692, for 192851 and 192875 |
| 193294 | --- | SINGER Light (moulded, less lamp), complete, Nos. 691j, 97359, 191785, 193248, 193289, 193400, 193421, 193431, 193437, 701842, and two 191786 |
| 193522 | --- | Motor Frame for 193545 |
| 193523 | 4959 | Armature Shaft Bearing Sleeve (commutator end) for 193545 |
| 193524 | 4959 | Armature Shaft Bearing Sleeve (front end) for 193545 |
| 193525 | --- | Grease Wick 193526 with 193527, for 15K91 Machine |
| 193526 | 4959 | Grease Wick for 193525 |
| 193527 | 4959 | Grease Wick Spring for 193525 |
| *193528 | --- | Armature Shaft for 15K91 Machine ... |
| 193529 | 4959 | Armature Shaft Pinion (spiral) with two 462a1, for 15K91 Machine |
| 193536 | 4960 | Commutator, complete, for 15K91 Machine |
| *193540 | --- | Armature Core, complete, for 15K91 Machine |
| 193541 | 4960 | Field Core, complete, for 15K91 Machine ... |
| 193542 | 4959 | Armature Shaft Oil Sling for 15K91 Machine |
| 193543 | 4959 | Brush Cap for 15K91 Machine |
| 193544 | 4960 | Motor Cover for 15K91 Machine |
| 193545 | 4960 | Motor Frame 193522 with 193523, 193524, two each 447c and 882e, for 193644 |
| 193546 | 4959 | Brush Tube Insulating Bushing for 15K91 Machine |
| 193555 | 4960 | Armature, complete, for P.G.K. 3 Motor for 15K91 Machine |
| 193556 | --- | Armature, complete, for P.G.K. 5 Motor for 15K91 Machine |
| 193557 | --- | Armature, complete, for P.G.K. 6 and P.G.K. 7 Motors for 15K91 Machine |
| 193558 | --- | Armature, complete, for P.G.K. 8 Motor for 15K91 Machine |
| 193559 | --- | Armature, complete, for P.G.K. 9 Motor for 15K91 Machine |
| 193560 | --- | Armature, complete, for P.G.K. 10 and P.G.K. 92 Motors for 15K91 Machine ... |
| 193561 | 2090 | Armature, complete, for P.G.K. 11 and P.G.K. 12 Motors for 15K91 Machine ... |
| 193562 | --- | Armature, complete, for P.G.K. 15 Motor for 15K91 Machine |

| No. | Plate | |
|--------|-------|---|
| 193563 | — | Armature, complete, for P.G.K. 87 Motor for 15K91 Machine |
| 193564 | — | Armature, complete, for P.G.K. 90 Motor for 15K91 Machine |
| 193565 | — | Field Coil, complete, Nos. 193566 and 193567, for P.G.K. 3 Motor for 15K91 Machine |
| 193566 | — | Field Coil (left) for 193565 |
| 193567 | — | Field Coil (right) for 193565 |
| 193568 | — | Field Coil, complete, Nos. 193569 and 193570, for P.G.K. 5 Motor for 15K91 Machine |
| 193569 | — | Field Coil (left) for 193568 |
| 193570 | — | Field Coil (right) for 193568 |
| 193571 | — | Field Coil, complete, Nos. 193572 and 193573, for P.G.K. 6 Motor for 15K91 Machine |
| 193572 | — | Field Coil (left) for 193571 |
| 193573 | — | Field Coil (right) for 193571 |
| 193574 | — | Field Coil, complete, Nos. 193575 and 193576, for P.G.K. 7 Motor for 15K91 Machine |
| 193575 | — | Field Coil (left) for 193574 |
| 193576 | — | Field Coil (right) for 193574 |
| 193577 | — | Field Coil, complete, Nos. 193578 and 193579, for P.G.K. 8 Motor for 15K91 Machine |
| 193578 | — | Field Coil (left) for 193577 |
| 193579 | — | Field Coil (right) for 193577 |
| 193580 | — | Field Coil, complete, Nos. 193581 and 193582, for P.G.K. 9 Motor for 15K91 Machine |
| 193581 | — | Field Coil (left) for 193580 |
| 193582 | — | Field Coil (right) for 193580 |
| 193583 | — | Field Coil, complete, Nos. 193584 and 193585, for P.G.K. 10 and P.G.K. 11 Motors for 15K91 Machine |
| 193584 | — | Field Coil (left) for 193583 |
| 193585 | — | Field Coil (right) for 193583 |
| 193586 | 2090 | Field Coil, complete, Nos. 193587 and 193588, for P.G.K. 12 Motor for 15K91 Machine |
| 193587 | — | Field Coil (left) for 193586 |
| 193588 | — | Field Coil (right) for 193586 |
| 193589 | — | Field Coil, complete, Nos. 193590 and 193591, for P.G.K. 15 Motor for 15K91 Machine |
| 193590 | — | Field Coil (left) for 193589 |
| 193591 | — | Field Coil (right) for 193589 |
| 193592 | — | Field Coil, complete, Nos. 193593 and 193594, for P.G.K. 87 Motor for 15K91 Machine |
| 193593 | — | Field Coil (left) for 193592 |
| 193594 | — | Field Coil (right) for 193592 |
| 193595 | — | Field Coil, complete, Nos. 193596 and 193597, for P.G.K. 90 Motor for 15K91 Machine |

| No. | Plate | |
|---|-------|---|
| 193596 | — | Field Coil (left) for 193595 |
| 193597 | — | Field Coil (right) for 193595 |
| 193598 | — | Field Coil, complete, Nos. 193599 and 193600, for P.G.K. 92 Motor for 15K91 Machine |
| 193599 | — | Field Coil (left) for 193598 |
| 193600 | — | Field Coil (right) for 193598 |
| 193629 | 4964 | Three-Pin Terminal Body (male half) Bracket for 15K91 Machine |
| 193640 | 4959 | Grease Wick Spring Retainer for 15K91 Machine |
| *193644 | — | Motor Frame 193545, with 190b, 51303b, 51319b, 125326, 125365, 125366, 125376 and 125462 for 15K91 Machine |
| *193700 | — | Three-Pin Terminal Body (male half) 192642 with three 192793, for 192797 |
| 193799 | — | Brush (carbon) for 150 to 250 volts for 15K91 Machine |
| 194113 | 2091 | Brush Tube for 15K91 Machine |
| 194120 | — | SINGER Light Lamp |
| <i>NOTE.—When ordering 194120 state voltage required.</i> | | |
| 194591 | — | Brush (carbon) for 25 and 32 volts for 15K91 Machine |
| 195834 | — | Field Coil Lead Terminal Clip for 15K91 Machine |
| 195834 | — | Lead Terminal Clip for 192875 |

NUMERICAL LIST OF PARTS

105

| No. | Plate | |
|--------|-------|--|
| 198052 | 2090 | Two-Pin Plug for 15K91 Machine ... |
| 198108 | ---- | Two-Pin Plug (Norwegian) for 15K91 Machine |
| 198138 | ---- | Two-Pin Plug (Danish) for 15K91 Machine |
| 198367 | ---- | Two-Pin Plug (Swiss) for 15K91 Machine ... |

108

NUMERICAL LIST OF PARTS

| No. | Plate | |
|--------|-------|--|
| 701719 | 2091 | Three-Pin Terminal Body (male half) Post Washer for 192797 |
| 727511 | 1959 | Field Coil Lead Bushing (rubber) for 15K91 Machine |
| 899418 | --- | Name Plate for P.G.K. 7 Motor |
| 899419 | --- | Name Plate for all P.G.K. Motors except P.G.K. 7 |
| 931275 | --- | Armature Wire Separator (linen) for 15K91 Machine |